


Wipers and washers


WIPER OPERATION



E132404


1. Rotate control to adjust sensitivity.
MAX: Rain sensor maximum sensitivity.
MIN: Rain sensor minimum sensitivity.
2. Fast speed wipe.
3. Normal speed wipe.
4. Rain sensor activated wipe.
5. Windscreen washer button.
6. Single wipe.

Sportbrake models have a different wiper control operation to facilitate the rear wash wipe.



E152066

1. Push to operate the rear wiper.
2. Rear wash.
3. Single wipe for front screen.

 Do not operate the windscreen wipers on a dry screen.