


Wipers and washers


WIPER OPERATION




E132404

1. Rotate control to adjust sensitivity.
MAX: Rain sensor maximum sensitivity.
MIN: Rain sensor minimum sensitivity.
2. Fast speed wipe.
3. Normal speed wipe.
4. Rain sensor activated wipe.
5. Windscreen washer button.
6. Single wipe.

Sportbrake models have a different wiper control operation to facilitate the rear wash wipe.



E152066

1. Push to operate the rear wiper.
 2. Rear wash.
 3. Single wipe for front screen.
-  Do not operate the windscreen wipers on a dry screen.