

12. Press to turn the touch screen on. Press twice to turn the screen off.

Note: For vehicles with Intelligent stop/start, this switch position is used to turn the feature off. To turn on the touch screen, simply touch the screen. To turn the screen off again, touch this icon on the screen.

TOUCH SCREEN USE

The buttons on the centre console below the touch screen display, are referred to as **hard buttons** and should be pressed firmly. The touch screen buttons are referred to as **soft keys** and require only light pressure to function. Do not use excessive pressure.

TOUCH SCREEN CARE



Do not use abrasive cleaners on the touch screen. For approved cleaning products, contact your Dealer/ Authorised Repairer.

TOUCH SCREEN SETUP

- Select **Set-up** from the **Home** menu.

The setup screen is divided into categories:

- **Screen**
- **System**
- **Voice**
- **Audio**
- **Trip computer**
- **Security/Vehicle**

SCREEN SETTINGS

- **Volume pop-up:** Display Volume pop-up on/off.
- **Screensaver:** Change screensaver.
- **Screen animations:** Turn animated transitions between screens on/off.

Note: While screen animations are on, system response time will be slower than normal.

- **Time out home:** Sub menu selection screens can be set to revert to the **Home** menu after a pre-determined length of time.
- **Theme:** Changes appearance of the touch screen soft keys.

SYSTEM SETTINGS

- **Button feedback:** Select to turn the soft key confirmation tone on/off.
- **Clock adjust:** Select 12 or 24 hour clock. Set current time. Select **Date** to change the date, or to alter the date format. Select **Set**, to store new settings.

Note: The clock can also be adjusted from the touch screen time display.

- **Home menu shortcuts:** Select up to 2 items from the displayed list to appear as shortcuts on the **Home menu**. Select **Clear** to deselect highlighted items.
- **Language:** Select the required language. Select **Male** or **Female** voice. Touch **Change** to select alternatives for Voice and text displays. Follow the on-screen instructions to confirm.

Note: Some languages are not yet available for both System display text and Voice control. In this event, it will be necessary to select a separate language for Voice control.

- **Volume presets:** Adjust volume for the available systems (announcements, parking aid, phone, voice etc.).