

A

- About this handbook.....2
- Accessories.....142
- Active differential control.....86
- Active exhaust.....75
- Adaptive dynamics.....87
- Adaptive front lighting system.....44
 - warning lamp.....39
- Adaptive headlamps.....44
- After a collision
 - pedestrian protection system.....197
- Age degradation (tyres).....181
- Airbags
 - cover cleaning.....152
 - curtain.....32
 - deployment.....31, 33
 - disability modifications.....34
 - disabling.....33
 - front.....32
 - locations.....31
 - maintenance.....142
 - service information.....34
 - side.....32
 - warning lamp.....33, 40
- Air conditioning
 - automatic recirculation.....63
 - driver controls.....
 - front.....62
- Air quality sensor.....63
- Alarm.....17, 142
 - automatic relocking and arming.....18
 - battery backed sounder.....17
 - deactivating.....17
 - passive arming.....17
 - perimeter.....17
 - security sensor fault.....18
 - tilt sensor.....17
- Anchor points (luggage).....68
- Anti-lock braking system (ABS) warning lamp.....39
- Anti-theft system.....142
- Anti-trap protection
 - windows.....58
- Approach lamps.....44
- Audible warnings.....42
- Audio
 - automatic station retune.....103
 - CD loading.....98
 - changing portable media device.....111
 - connecting portable media devices.....109
 - DAB radio
 - controls.....104
 - settings.....105
 - stations.....106
 - DVD player controls.....115
 - full screen view.....116
 - licensing.....99, 101
 - portable media connections.....108
 - portable media controls.....107
 - portable media pairing.....110–111
 - portable media playing.....110
 - radio controls.....102
 - sound settings.....98
 - touch screen controls.....97
 - TV controls.....113
 - video player controls.....115
- Auto lamps
 - wiper detection.....44
- Automatic locking.....9, 18
- Automatic recirculation.....63
- Automatic speed limiter
 - warning lamp.....40
- Automatic transmission.....78
 - gear shift warning lamp.....41
 - shift paddles.....79
 - temporary manual selection.....79
- Auto zoom (navigation).....126
- Auxiliary device connection.....110

B

- Battery
 - boost starting.....162
 - care.....159
 - charging.....162
 - connecting jump leads.....160
 - disconnecting jump leads.....162
 - maintenance.....159

- monitoring system.....160
 - replacing.....162
 - using a starting aid.....162
 - warning symbols.....159
 - Battery backed sounder.....17
 - Blind spot monitor
 - closing vehicle sensing.....53
 - displayed messages.....54
 - notification of overtaking vehicle.....52
 - sensor blockage.....54
 - Bluetooth
 - compatibility.....118
 - pairing
 - via the phone.....119
 - portable media
 - pairing.....110–111
 - playing.....110
 - telephone.....118
 - icons.....120
 - overview.....117
 - pairing.....119
 - phonebook.....121
 - safety.....118
 - Bonnet
 - closing.....145
 - opening.....144
 - Booster seats for larger children.....30
 - Boost starting.....162
 - Brakes
 - ABS warning lamp.....39
 - brake pads.....143
 - electronic brake force distribution.....88
 - emergency brake assist.....88
 - fluid check.....156
 - fluid specification.....156
 - fluid top up.....156
 - handbrake.....89
 - important information.....88
 - parking brake warning lamp.....39
 - pedal travel.....206
 - warning lamp (red).....38
 - warning lamp (yellow).....39
 - Bulbs
 - changing a bulb.....146
 - rear fog lamp.....147
 - reverse lamps.....148
 - specification.....205
- ## C
- Call volume.....121
 - Cameras
 - rear camera.....91, 94
 - reverse traffic detection.....93
 - Capacities.....205
 - Carpets and mats.....152
 - Car-wash.....150
 - CD player
 - CD loading.....98
 - portable media pairing.....110–111
 - portable media playing.....110
 - Change a connected phone.....120
 - Changing a bulb.....146
 - Changing a fuse.....164
 - Changing a wheel
 - locking wheel nuts.....192
 - recommended process.....191
 - safety warnings.....190
 - Charging the vehicle battery.....162
 - Chassis number.....199
 - Child safety
 - booster seats.....30
 - check list.....29
 - child seats.....28
 - larger children.....30
 - positioning.....30
 - recommended child seats.....30
 - Cleaning
 - airbag covers.....152
 - alloy wheels.....150
 - automatic car wash.....150
 - carpets and mats.....152
 - exterior.....150
 - paintwork.....150
 - glass.....151
 - interior.....151–152
 - leather.....151
 - parking sensors.....91
 - polishing.....151

- rear screen.....151
- removing grease.....151
- removing stains.....152
- removing tar.....151
- seat belts.....152
- using a car-wash.....150
- washer jets.....146
- Climate control
 - automatic recirculation.....63
 - driver controls.....
 - front.....62
 - heated seats.....63
- Clock.....35
- Closing the bonnet.....145
- Closing vehicle sensing.....53
- Compact disc.....98
- Condensation (headlamps).....45
- Conformity declarations.....136, 209
- Connecting jump leads.....160
- Controls
 - driving position.....
 - overview.....
- Convertible roof
 - closing.....69
 - manual re-set.....70
 - opening.....69
- Coolant
 - checking the level.....155
 - specification.....155
 - top up.....155
- Covers
 - refitting.....146
 - removal.....145
- Critical warning messages.....38
- Cruise control.....96
 - warning lamp.....41
- D**
- DAB radio
 - ensembles.....106
 - settings.....105
- DAB radio controls.....104
- Data recording.....197–198
- Daytime running lamps.....44
- Dealer locations.....131
- Declarations of conformity.....209
 - navigation system.....136
- Deselecting valet mode.....61
- Destination entry.....127
 - postcode.....130
 - search area.....127
- Diesel
 - filler flap.....139
 - specification.....139
- Differential control.....86
- Dimensions.....203
- Direction indicators.....43
 - warning lamp.....41
- Door mirrors.....50
 - blind spot monitor.....52
 - closing vehicle sensing.....53
 - sensors.....54
- Door transceiver
 - assistance.....57
 - erase all programming.....56
 - garage door opener.....55
 - programming.....55
 - programming a single button.....56
 - programming the garage door opener.....55
 - rolling code device programming.....56
- Double locking.....16
 - full alarm.....17
- Drive away locking.....9
- Drive control
 - operation.....82
- Driver controls.....
- Driving
 - activating intelligent stop/start.....76
 - active exhaust.....75
 - after a collision.....197
 - automatic speed limiter.....95
 - before starting.....197
 - blind spot monitor.....52
 - closing vehicle sensing.....53
 - blind spot monitor messages.....54
 - brakes important information.....88
 - daily checks.....143
 - deactivating intelligent stop/start.....76

Index

driver controls.....	
DSC active warning lamp.....	40
DSC configurable modes.....	84
DSC dynamic launch.....	83
DSC rain/ice/snow mode.....	82
electronic brake force distribution.....	88
emergency brake assist.....	88
gear shift warning lamp.....	41
rain sensor.....	48
running-in.....	142
sitting correctly.....	22
using cruise control.....	96
weekly checks.....	143
Driving abroad	
beam pattern.....	45
headlamps.....	45
Driving position memory.....	21
recalling a position.....	22
Dynamic launch	
DSC.....	83
Dynamic stability control (DSC).....	81–82
configurable.....	84
DSC active warning lamp.....	40
DSC off warning lamp.....	40
dynamic launch.....	83
rain/ice/snow mode.....	82
spoiler.....	85
switching between DSC and tracDSC.....	82
switching off.....	81
switching on.....	81
E	
Easy route.....	128
Electric parking brake.....	89
Electric roof	
closing.....	69
manual re-set.....	70
opening.....	69
Electric seats.....	19
position memory.....	21
recalling a memory position.....	22
restricted seat travel.....	22
Electric windows	
operation.....	58
Electronic brake force distribution.....	88
Electronic data.....	198
Emergency (navigation).....	130
Emergency brake assist.....	88
Emergency key locking.....	18
Emergency release	
luggage compartment.....	67
Engine	
antifreeze level.....	155
compartment opening.....	144
coolant level.....	155
oil level.....	153
running-in.....	142
specifications.....	200
starting	
keyless start backup.....	74
switching off.....	73
Engine/transmission warning lamp.....	40
Engine block heaters	
antifreeze.....	75
cold starting.....	75
connecting to mains supply.....	75
Engine compartment	
fluid filler locations.....	153
Engine covers	
refitting.....	146
removal.....	145
Engine starting.....	73
active exhaust.....	75
failure to start.....	74
Engine temperature warning lamp.....	38
Entering a destination.....	127
Entering the vehicle	
entry and exit mode.....	23
global opening.....	9
keyless entry.....	8
luggage compartment.....	10
tailgate operation.....	10
unlocking mode.....	8
Ethanol.....	137
EU conformity (navigation system).....	136
Event data recording.....	198
Exiting the vehicle	
arming the alarm.....	15, 18

closing mislock.....	16	power steering	
door locks and release levers.....	16	specification.....	157
double locking.....	16	power steering check.....	157
emergency locking.....	18	specifications.....	201
full alarm.....	17	washer fluid.....	158
global closing.....	16	check.....	158
interior locks.....	16	specification.....	158
passive arming.....	17	Fog lamps	
perimeter alarm.....	17	warning lamps	
single locking.....	16	rear.....	40
Exterior cleaning.....	150	Front airbags.....	32
Exterior lamps		Front climate control.....	62
bulb changing.....	146	automatic recirculation.....	63
bulb specification.....	205	Front parking aids.....	90
Exterior mirrors		system fault.....	91
electric.....	50	volume.....	91
manual.....	50	Front wipers.....	48
mirror dip when reversing.....	51	Fuel and refuelling.....	139
External temperature		consumption.....	140
warning lamp.....	40	ethanol.....	137
Extinguisher.....	149	filler flap.....	139
Extra features.....	61	fuel filler flap.....	138
F		fuel specification.....	139
Favourite locations		methanol.....	137
navigation.....	129	methyl tertiary butyl ether (MTBE).....	138
navigation details.....	129	octane rating.....	137
Fire extinguisher.....	149	running out.....	138
First aid kit.....	149	safety precautions.....	137
Flat spots.....	181	tank capacity.....	139
Fluids		Fuel consumption.....	140
brake		combined cycles.....	141
check.....	156	extra-urban cycle.....	140
specification.....	156	urban cycle.....	140
top up.....	156	Fuel filler flap.....	138
capacities.....	205	Fuel gauge.....	35
coolant		Fuel system.....	144
specification.....	155	Full screen view for video.....	116
top up.....	155	Fuses	
engine oil check.....	153	changing.....	164
filler locations.....	153	engine compartment fuse box.....	165
oil		locations.....	163
top up.....	154	luggage compartment fuse box.....	174
		passenger compartment fuse box.....	168

- G**
- Garage door opener.....55
 - assistance.....57
 - entry gate.....57
 - erase all programming.....56
 - programming.....55
 - programming a rolling code device.....56
 - programming a single button.....56
 - Gearbox
 - automatic.....78
 - driver controls.....
 - emergency park release.....195
 - gear shift warning lamp.....41
 - limp home mode.....80
 - operation.....82
 - Glass cleaning.....151
 - Global closing.....16
 - Global opening.....9
- H**
- Handbook symbols.....2
 - Handbrake.....89
 - Headlamps.....43
 - adaptive.....44
 - approach lamps.....44
 - beam pattern.....45
 - bulb changing.....146
 - bulb specification.....205
 - condensation.....45
 - daytime running lamps.....44
 - driver controls.....
 - driving abroad.....45
 - high beam assist.....44
 - high beam assist warning lamp.....41
 - high beam warning lamp.....41
 - warning lamp (AFS).....39
 - washers.....49
 - xenon.....146
 - Heated seats.....63
 - Heated steering wheel.....23
 - Heating and ventilation.....62
 - automatic recirculation.....63
 - driver controls.....
 - front.....62
 - heated seats.....63
 - High beam assist.....44
 - Home (navigation).....130
 - Homelink.....55
 - assistance.....57
 - erase all programming.....56
 - gate/door opener.....57
 - programming.....55
 - programming a single button.....56
 - programming the garage door opener.....55
 - rolling code device programming.....56
- I**
- Ignition
 - rolling re-start.....73
 - switching on.....73
 - Indicators warning lamp.....41
 - Information messages.....38
 - Infotainment
 - automatic station retune.....103
 - CD loading.....98
 - DAB radio
 - settings.....105
 - stations.....106
 - DAB radio controls.....104
 - full screen view.....116
 - media player controls.....115
 - portable media
 - changing.....111
 - connecting devices.....109
 - connecting multiple devices.....110
 - connections.....108
 - controls.....107
 - pairing.....110–111
 - playing.....110
 - radio controls.....102
 - sound settings.....98
 - touch screen
 - audio/video controls.....97
 - care.....60
 - extra features.....61
 - home menu.....59
 - operating.....60

settings.....	60
setup.....	60
TV controls.....	113
Instrument panel.....	35, 152
display units.....	37
fuel range.....	37
lamp test.....	38
menu.....	35
driving features.....	35
instrument display.....	35
trip computer.....	35
vehicle set-up.....	35
service indicator.....	37
warning lamps.....	38
warning messages.....	36
Intelligent stop/start	
activating.....	76
deactivating.....	76
Intelligent stop/start warning lamp.....	41
Interior cleaning.....	151–152
airbag covers.....	152
carpets and mats.....	152
Interior lamps.....	46
ambient lighting.....	46
bulb changing.....	146
bulb specification.....	205
intensity.....	46
types.....	46
Interior locking.....	16
Introduction	
instructional videos.....	3

J

Jump starting	
connecting a starting aid.....	162
connecting jump leads.....	160
disconnecting jump leads.....	162

K

Keyless entry.....	8
--------------------	---

L

Label locations.....	199
----------------------	-----

Lamps.....	43
auto lamps wiper detection.....	44
bulb changing.....	146
bulb specification.....	205
condensation.....	45
test.....	38
TPMS warning lamp.....	40
warning lamps.....	38
xenon headlamps.....	146
Leather cleaning.....	151
Licensing	
audio/video.....	99, 101
Lighting	
ambient lighting.....	46
interior lamps intensity.....	46
interior lamps locations.....	46
Limp home mode.....	80
Load carrying	
cover.....	67
Load securing.....	68
Loadspace	
emergency release.....	67
Loadspace cover.....	67
Locking	
automatic relocking.....	18
door locks and release levers.....	16
double locking.....	15–16
drive away.....	9
emergency locking.....	18
global closing.....	16
in an emergency.....	18
mislock.....	16
security sensor fault.....	18
single.....	16
single locking.....	15
with the emergency key.....	18
Locking wheel nuts.....	192
Lubricants specifications.....	201
Luggage compartment	
anchor points.....	68
cover.....	67
emergency release.....	67

- M**
- Maintenance
- brake fluid level.....156
 - brake pads.....143
 - bulb changing.....146
 - bulb specification.....205
 - capacities.....205
 - changing a fuse.....164
 - checking tyre pressure after a repair.....188
 - cleaning
 - alloy wheels.....150
 - exterior.....150
 - glass.....151
 - interior.....151–152
 - leather.....151
 - parking sensors.....91
 - rear screen.....151
 - seat belts.....152
 - closing the bonnet.....145
 - daily checks.....143
 - disconnecting jump leads.....162
 - engine compartment fuse box.....165
 - engine coolant level.....155
 - engine oil level.....153
 - fuel system.....144
 - fuse box (passenger compartment).....168
 - jump starting.....162
 - label locations.....199
 - lubricants and fluid specifications.....201
 - luggage compartment fuse box.....174
 - oil top up.....154
 - paintwork repair.....150
 - polishing.....151
 - power steering fluid level.....157
 - removing grease and tar.....151
 - removing stains.....152
 - running-in.....142
 - smart key battery.....13
 - tyre repair kit.....186
 - tyre repair procedure.....187
 - using a starting aid.....162
 - washer fluid level.....158
 - washer jets.....146
 - weekly checks.....143
 - wheel balancing.....143
- Manual seats.....21
- Map.....130
- auto zoom.....126
 - split screen.....126
- Message centre display units.....37
- Methanol.....137
- Minor paintwork repairs.....150
- Mirrors
- blind spot monitor.....52
 - closing vehicle sensing.....53
 - sensors.....54
 - dip when reversing.....51
 - driver controls.....
 - exterior mirrors.....50
- Motorway
- destination entry.....130
- Mpg.....140
- N**
- Navigation
- Arabic language.....132
 - automatic route learning.....128
 - avoid points.....128
 - destination entry.....127
 - search area.....127
 - destination entry by postcode.....130
 - easy route.....128
 - emergency contacts.....130
 - favourite locations.....129
 - home location.....130
 - legals.....134–136
 - licence terms.....134–135
 - licensing.....134–136
 - map.....130
 - auto zoom.....126
 - split screen.....126
 - menu.....124
 - motorway selection.....130
 - operating.....122
 - overview.....122
 - points of interest (POI).....131–132
 - categories/sub-categories.....131

search.....	131	operating.....	90
previous destinations.....	130	rear camera.....	91, 94
quick POI selection.....	129	reverse traffic detection.....	93
restore defaults.....	129	system fault.....	91
screen modes.....	127	volume.....	91
start guidance.....	128	Parking brake.....	89
TMC.....	132, 134	warning lamp.....	39
icons.....	133	Park position emergency release.....	195
voice guidance.....	129	Parts.....	142
warranty disclaimer.....	136	Passenger compartment fuse box.....	168
O		Passive alarm arming.....	17
Occupant safety		Pedestrian protection system.....	197
cleaning seat belts.....	152	after deployment.....	197
recommended child seats.....	30	Perimeter alarm.....	17
seat belt pre-tensioners.....	26	Petrol	
seat belt reminder warning.....	26	specification.....	139
seat belt safety.....	25	Petrol consumption.....	140
seat belts warning lamp.....	39	Petrol filler flap.....	139
using seat belts.....	24	Phone	
Octane rating.....	137	Bluetooth compatibility.....	118
Oil		call volume.....	121
engine oil specification.....	154	change the phone.....	120
filler locations.....	153	icons.....	120
specification.....	201	overview.....	117
top up.....	154	pairing via the phone.....	119
used engine oil.....	144	pairing via the touch screen.....	119
Opening the bonnet.....	144	phonebook.....	121
Oversteer.....	81	safety.....	118
Overview		steering wheel controls.....	120
driver controls.....		Points of interest (POI).....	131
Owner maintenance.....	143	my POI.....	132
P		search.....	131
Paddle shift.....	79	Polishing the bodywork.....	151
Paintwork		Portable media	
cleaning.....	150	changing device.....	111
repair.....	150	connecting devices.....	109
Pairing		connecting multiple devices.....	110
via the phone.....	119	connections.....	108
Pairing a phone.....	119	controls.....	107
Parking aids		pairing.....	110–111
cleaning the sensors.....	91	playing.....	110
		Postcode	
		destination entry.....	130
		Powered tailgate.....	12

Power steering	
fluid	
specification.....	157
fluid level.....	157
Pressure checking (tyres)	
checking after a repair.....	188
Pressures	
tyres.....	177
Previous destination.....	130
Punctured tyres.....	180
Puncture repair kit.....	186
instructions for use.....	187
repair procedure.....	187
safety.....	186

Q

QR codes for smart phones	
instructional videos.....	3
Quick POI selection.....	129

R

Radio	
automatic station retune.....	103
controls.....	102
DAB	
settings.....	105
stations.....	106
DAB controls.....	104
Radio data system auto retune.....	103
Radio frequency regulations.....	208
Rain sensor.....	48
RDS	
TMC	
icons.....	133
overview.....	132
Rear camera	
parking aids.....	91
reverse traffic detection.....	93
sensors.....	94
Rear fog lamps warning lamp.....	40
Rear screen cleaning.....	151
Recalling seat memory position.....	22

Recording	
event data.....	198
service data.....	197
Recovery	
towing eyes.....	194
transmission park release.....	195
transporting.....	195
Refuelling	
ethanol.....	137
fuel filler flap.....	138
methanol.....	137
MTBE.....	138
octane rating.....	137
running out of fuel.....	138
safety precautions.....	137
Reminder (seat belt).....	26
Remote control	
care.....	13
driving position memory.....	21
single locking.....	16
smart key battery.....	13
system transmitters.....	206
Removing stains.....	152
Repairing paintwork damage.....	150
Replacement tyres.....	180
Resetting the windows.....	148
Restarting the engine while moving.....	73
Restore navigation default settings.....	129
Restricted seat travel.....	22
Reverse lamps	
bulb changing.....	148
Reverse parking aids.....	90
rear camera.....	94
reverse traffic detection.....	93
system fault.....	91
volume.....	91
Rolling re-start.....	73
Route.....	127
favourite locations.....	129
favourites details.....	129
Running-in.....	142
Running out of fuel.....	138

S

- Safety
 - cleaning seat belts.....152
 - fuel and refuelling.....137
 - seat belt pre-tensioners.....26
 - seat belt reminder warning.....26
 - seat belts.....25
 - seat belts warning lamp.....39
 - seats for larger children.....30
 - sitting correctly.....22
 - TPMS pressure compensation.....181
 - tyre care.....177
 - tyre pressures.....177
 - used engine oil.....144
 - using seat belts.....24
 - using the telephone.....118
 - warning triangle.....148
- Safety in the garage
 - battery precautions.....143
 - electrical components.....143
 - engine fans.....143
 - exhaust gases.....143
 - hot components.....143
 - jacking.....143
- Satellite navigation
 - Arabic language.....132
 - automatic route learning.....128
 - avoid points.....128
 - cancel guidance.....129
 - coordinates entry.....130
 - dealer locations.....131
 - destination entry.....127
 - search area.....127
 - destination entry by postcode.....130
 - easy route.....128
 - emergency contacts.....130
 - favourite locations.....129
 - home location.....130
 - legals.....134–136
 - licence terms.....134–135
 - licensing.....134–136
 - map.....130
 - auto zoom.....126
 - split screen.....126
 - menu.....124
 - motorway selection.....130
 - operating.....122
 - overview.....122
 - points of interest (POI).....131–132
 - categories.....131
 - search.....131
 - previous destinations.....130
 - quick POI selection.....129
 - restore defaults.....129
 - screen modes.....127
 - start guidance.....128
 - TMC.....132, 134
 - icons.....133
 - voice guidance.....129
 - warranty disclaimer.....136
 - Screen modes.....127
 - Screen settings
 - screensaver.....60
 - theme.....60
 - time out period.....60
 - volume pop-up.....60
 - Screen wash
 - check.....158
 - specification.....201
 - topping up.....158
 - Search area (navigation).....127
 - Seat belts.....24, 152
 - adjusting.....24
 - checks.....25
 - pre-tensioners.....26
 - reminder warning.....26
 - safety.....25
 - warning lamp.....39
 - Seats
 - child restraint check list.....29
 - child seat positioning.....30
 - child seats.....28
 - cleaning seat belts.....152
 - electric front.....19
 - heated.....63
 - manual front.....21
 - position memory.....21

recalling a memory position.....	22
recommended child seats.....	30
restricted seat travel.....	22
seat belts warning lamp.....	39
sitting correctly.....	22
Securing luggage.....	68
Security.....	17
alarm.....	142
tilt sensor.....	17
automatic perimeter alarm.....	17
automatic relocking and arming.....	18
battery backed sounder.....	17
closing mislock.....	16
deactivating the alarm.....	17
locking with the emergency key.....	18
perimeter alarm.....	17
single locking.....	16
Security sensors	
fault.....	18
Selecting valet mode.....	61
Sensors	
blockage (BSM).....	54
Servicing	
airbags.....	34
data recording.....	197
Set speed limit.....	95
Settings menu.....	35
display units.....	37
Side lamps warning lamp.....	41
Silencing the alarm.....	17
Sitting correctly.....	22
Smart key	
approach lamps.....	44
battery changing.....	13
care.....	13
driving position memory.....	21
single locking.....	16
transmitters.....	206
Smart phone video	
qR codes.....	3
Snow chains.....	182
Soft top roof	
closing.....	69
manual re-set.....	70
opening.....	69
Sound settings.....	98
Specifications	
brake pedal travel.....	206
dimensions.....	203
engine.....	200
ethanol.....	137
fluids.....	201
fuel.....	139
fuel tank capacity.....	139
label locations.....	199
lubricants.....	201
methanol.....	137
MTBE.....	138
weight.....	202
wheel alignment.....	206
Speed-dependent wipers.....	48
Speed limiting.....	95
Speedometer.....	35
Split screen map.....	126
Spoiler	
manual mode.....	85
SRS.....	31
airbag warning lamp.....	40
Stability control	
DSC.....	81–82
configurable.....	84
dynamic launch.....	83
rain/ice/snow mode.....	82
switching between DSC and tracDSC.....	82
switching on.....	81
spoiler.....	85
switching off.....	81
tracDSC.....	81
Starting after a collision.....	197
Starting the engine.....	73
active exhaust.....	75
engine block heaters.....	75
failure to start.....	74
keyless start backup.....	74
Start navigation guidance.....	128
Steering column	
lock.....	9
vehicle recovery.....	9

Steering wheel	
adjusting.....	23
AUTO position.....	23
heated.....	23
Steering wheel controls	
speed limiter.....	95
telephone.....	120
Stop/start	
activating.....	76
deactivating.....	76
Storage compartments.....	65
cup holders.....	65
front cubby box.....	65
rear armrest.....	65
Storage compartments areas	
glove box.....	65
Supplementary restraint system (SRS)	
airbag deployment.....	33
airbag locations.....	31
airbags maintenance.....	142
airbag warning lamp.....	33, 40
curtain airbags.....	32
front airbags.....	32
side airbags.....	32
Suspension	
adaptive dynamics.....	87
Switching off the engine.....	73
Switching on the ignition.....	73
T	
Tachometer.....	35
Tailgate.....	6
opening and closing.....	12
Technical specifications	
radio frequency regulations.....	208
weights.....	202
wheel alignment.....	206
Telephone.....	117
Bluetooth compatibility.....	118
call volume.....	121
change the phone.....	120
compatibility list.....	118
hands free operation.....	118
icons.....	120
overview.....	117
pairing.....	119
via the phone.....	119
phonebook.....	121
safety.....	118
steering wheel controls.....	120
Television	
controls.....	113
Tilt sensor.....	17
Timed jet function.....	49
TMC.....	132
Touch screen.....	152
audio/video controls.....	97
automatic recirculation.....	63
button feedback.....	60
changing portable media device.....	111
clock.....	60
connecting multiple portable media devices.....	110
connecting portable media devices.....	109
DAB radio controls.....	104
DVD player controls.....	115
extra features.....	61
front climate control.....	62
heated seats.....	63
home menu.....	59
inhibited display.....	116
language selection.....	60
operating.....	60
portable media	
controls.....	107
portable media connections.....	108
portable media pairing.....	110–111
portable media playing.....	110
radio controls.....	102
screen settings.....	60
setup.....	60
shortcuts.....	60
system settings.....	60
telephone	
pairing.....	119
phonebook.....	121
touch screen care.....	60
TV controls.....	113

- valet mode.....61
 - video player controls.....115
 - volume presets.....60
 - Tow eye (front).....194
 - Towing
 - eyes.....194
 - tracDSC.....81
 - Traction control
 - switching between DSC and tracDSC.....82
 - switching off.....81
 - switching on.....81
 - tracDSC.....81
 - Traffic message channel (TMC).....134
 - Transmission
 - automatic.....78
 - driver controls.....
 -195
 - gear shift warning lamp.....41
 - limp home mode.....80
 - operation.....82
 - Transmission park release.....195
 - Transmitters
 - smart key.....206
 - Transporting the vehicle.....195
 - Trip computer.....36
 - average speed.....36
 - fuel consumption.....36
 - fuel range.....37
 - reset.....36
 - trip distance.....37
 - Turning on the engine
 - active exhaust.....75
 - engine block heaters.....75
 - TV
 - controls.....113
 - Tyre pressure checking after a repair.....188
 - Tyre pressure monitoring system (TPMS)..184
 - tyre care.....177
 - valves.....180
 - warning lamp.....40
 - Tyre repair kit
 - checking pressures.....188
 - repair procedure.....187
 - safety information.....186
 - using.....187
 - Tyres
 - age degradation.....181
 - changing.....184
 - flat spots.....181
 - important information.....193
 - Indian regulations.....183
 - pressures.....177
 - punctured.....180
 - repair kit.....186
 - repair kit use.....187
 - repair procedure.....187
 - replacements.....180
 - snow chains.....182
 - speed ratings.....177
 - temporary use spare.....184
 - TPMS.....184
 - warning lamp.....40
 - TPMS pressure compensation.....181
 - tyre care.....177
 - tyre repair safety.....186
 - tyre wall markings.....176
 - use of spare tyre.....193
 - valves.....180
 - wall markings.....176
 - wheel and tyre sizes.....183
 - winter.....181
- ## U
- Under bonnet covers.....145–146
 - Understeer.....81
 - Unlocking.....16
 - all doors.....6
 - driver's door.....6
 - entry and exit mode.....23
 - global opening.....6, 9
 - keyless entry.....8
 - luggage compartment.....10
 - luggage compartment emergency
 - release.....67
 - mode.....6
 - multi point entry.....6, 8
 - opening the tailgate.....12
 - single point entry.....6, 8

USB devices	
connecting multiple devices.....	110
Used engine oil.....	144
Using cruise control.....	96
Using the parking aids.....	90
Using the spare tyre	
important information.....	193

V

Valet mode.....	61
deselecting.....	61
Vehicle alarm.....	142
Vehicle battery	
battery monitoring system.....	160
connecting jump leads.....	160
replacing.....	162
warning symbols.....	159
Vehicle battery care.....	159
Vehicle cleaning	
airbag covers.....	152
alloy wheels.....	150
automatic car wash.....	150
carpets and mats.....	152
interior.....	151–152
parking sensors.....	91
rear screen.....	151
washer jets.....	146
Vehicle data recording.....	198
Vehicle recovery	
attaching the front tow eye.....	194
steering column lock.....	9
towing eyes.....	194
transmission park release.....	195
transporting the vehicle.....	195
Vehicle weights.....	202
Video media player	
controls.....	115
full screen view.....	116
inhibited display.....	116
VIN number.....	199
Voice guidance.....	129
Volume	
parking.....	91
telephone.....	121

W

Warning lamps.....	38
ABS.....	39
adaptive front lighting system (AFS).....	39
airbags.....	33, 40
audible warnings and indicators.....	42
automatic speed limiter.....	40
brake.....	38–39
critical warning message.....	38
cruise control.....	41
DSC active.....	40
engine/transmission.....	40
engine temperature.....	38
external temperature.....	40
gear shift warning lamp.....	41
headlamp high beam.....	41
high beam assist.....	41
indicators.....	41
intelligent stop/start (green).....	41
lamp test.....	38
parking brake.....	39
rear fog lamps.....	40
seat belt.....	39
side lights.....	41
tyre pressure monitoring system (TPMS).....	40
Warning triangle.....	148
Washer jets.....	146
Washers.....	48
fluid specification.....	158
fluid top up.....	158
headlamps.....	49
timed jet function.....	49
windscreen.....	49
Washing	
automatic car wash.....	150
exterior paintwork.....	150
removing grease.....	151
removing stains.....	152
removing tar.....	151
Weights.....	202
Wheel balancing.....	143

- Wheel changing
 - important information.....193
 - locking wheel nuts.....192
 - recommended process.....191
 - safety warnings.....190
 - tilt sensor.....191
 - use of spare tyre.....193
- Wheels and tyres
 - age degradation.....181
 - changing a tyre.....184
 - checking the pressures after a repair.....188
 - flat spots.....181
 - Indian regulations.....183
 - pressures.....177
 - punctured.....180
 - puncture repair.....186
 - puncture repair safety.....186
 - repair kit.....186
 - repair kit use.....187
 - repair procedure.....187
 - replacements.....180
 - snow chains.....182
 - specified sizes.....183
 - temporary use spare.....184
 - TPMS.....184
 - TPMS pressure compensation.....181
 - TPMS warning lamp.....40
 - tyre care.....177
 - tyre speed ratings.....177
 - tyre wall markings.....176
 - valves.....180
 - wheel alignment.....206
 - winter tyres.....181
- Wheel spin.....81
- Windows
 - anti-trap protection.....58
 - driver controls.....
 - operation.....58
 - reset.....148
- Winter tyres.....181
- Wipers and washers.....48
 - drip wipe.....49
 - driver controls.....
 - fluid level.....158
 - rain sensor.....48
 - speed-dependent mode.....48
 - timed washer jet function.....49
 - windscreen washers.....49

X

- Xenon headlamps.....146

