

XFR-S Sportbrake - up to 250 km/h (155 mph)				
	Up to 3 occupants		Maximum Gross Vehicle Weight (GVW)	
Tyre size	Front pressures bar (psi, kPa)	Rear pressures bar (psi, kPa)	Front pressures bar (psi, kPa)	Rear pressures bar (psi, kPa)
265/35 ZR20 99Y	2.5 (36, 250)	-	2.5 (36, 250)	-
295/30 ZR20 101Y	-	2.5 (36, 250)	-	2.5 (36, 250)


XFR-S Sportbrake - over 250 km/h (155 mph)				
	Up to 3 occupants		Maximum Gross Vehicle Weight (GVW)	
Tyre size	Front pressures bar (psi, kPa)	Rear pressures bar (psi, kPa)	Front pressures bar (psi, kPa)	Rear pressures bar (psi, kPa)
265/35 ZR20 99Y	2.8 (41, 280)	-	3.2 (46, 320)	-
295/30 ZR20 101Y	-	2.8 (41, 280)	-	3.2 (46, 320)

Saloon and Sportbrake - temporary-use spare tyre - maximum 80 km/h (50 mph)			
Tyre size	Load/speed index	Front pressures bar (psi, kPa)	Rear pressures bar (psi, kPa)
135/80 R18	104M	4.2 (60, 420)	4.2 (60, 420)
135/70 R19	105M	4.2 (60, 420)	4.2 (60, 420)




See 201, **IMPORTANT – USE OF SPARE TYRE.**

TYRE VALVES

Keep the valve caps screwed down firmly to prevent water or dirt from entering the valve. Check the valves for leaks when checking the tyre pressures.

-  Do not twist or bend the valves when attaching a pressure hose or gauge, as damage may result.

REPLACEMENT TYRES

-  Always fit replacement tyres of the same type, and wherever possible, of the same make and tread pattern.
-  The load and speed index ratings on all replacement tyres must be, at least, the same specification as the Original Equipment (OE). If in doubt, consult your Dealer/Authorised Repairer.
-  Do not rotate tyres around the vehicle.