


WIPER OPERATION



1. Automatic rain sensing mode (AUTO): The front wipers will respond and adapt automatically to the ambient rain conditions, selecting the appropriate wiper frequency for the prevailing conditions.
2. Rotate the collar to adjust the sensitivity of the Automatic rain sensing mode when position (1) is selected. The higher the sensitivity position, the more responsive the wipers will become. When AUTO position is selected, or when sensitivity is increased, the wipers will perform a single wipe.
3. Low speed continuous wipe.
4. High speed continuous wipe.

⚠ Make sure the wipers are switched off before entering a car wash. If the Automatic rain sensing mode operates during the car washing process, damage may occur to the wiper mechanism.

⚠ Do not operate the wipers on a dry windscreen.

⚠ In freezing or very hot conditions, make sure that the wipers have not stuck to the windscreen before operating.

⚠ Remove any snow, ice, or frost from the windscreen, around the wiper arms and blades, and the screen scuttle, before operating the wipers.

5. Pull the control towards the driver for a single wipe, or hold for further continuous wipes.
6. Windscreen wash/wipe: Press and release to start a wash/wipe programme consisting of a number of low speed wipes. Washer fluid is sprayed during the up-stroke of the first 2 wipes. Continue to hold if additional washer fluid is required. A few seconds after the programme finishes, a drip wipe will clear any residual fluid from the windscreen.

Note: Check and top-up the washer fluid level at least every week. See **170, CHECKING THE WASHER FLUID LEVEL.**

Note: When the wipers are operated for 20 wipes or more, Windscreen wiper detection will switch on the vehicle's lights. See **48, WINDSCREEN WIPER DETECTION.**



Sportbrake models have a different wiper/washer control operation to facilitate the rear wash wipe.

1. Push to operate the rear wiper.
2. Rear wash.