

PASSENGER COMPARTMENT FUSE BOX

Fuse No	Rating (amps)	Fuse Colour	Circuit
F1	250A	-	Control module.
F2	-	-	-
F3	20A	Yellow	Driver's seat adjustment.
F4	20A	Yellow	Driver's seat adjustment.
F5	20A	Yellow	Left side rear door controls.
F6	-	-	-
F7	-	-	-
F8	-	-	-
F9	20A	Yellow	Front passenger's seat adjustment.
F10	20A	Yellow	Front passenger's seat adjustment.
F11	20A	Yellow	Right side rear door controls.
F12	-	-	-
F13	-	-	-
F14	-	-	-
F15	5A	Tan	Brake pedal switch.
F16	5A	Tan	Instrument pack.
F17	-	-	-
F18	5A	Tan	Integrated control panel.
F19	15A	Blue	Sunroof.
F20	10A	Red	Driver's seat adjustment.
F21	-	-	-
F22	-	-	-
F23	10A	Red	Air conditioning.
F24	-	-	-
F25	-	-	-
F26	10A	Red	Front passenger's seat adjustment.
F27	20A	Yellow	Driver's heated/climate seat.
F28	-	-	-

Fuse No	Rating (amps)	Fuse Colour	Circuit
F29	20A	Yellow	Front passenger's heated/climate seat.
F30	5A	Tan	Diagnostics.
F31	5A	Tan	Anti theft system.
F32	-	-	-
F33	-	-	-
F34	5A	Tan	Instrument pack.
F35	5A	Tan	Electric parking brake.
F36	10A	Red	Column adjust.