

- all doors.....4
- driver's door.....4
- entry and exit mode.....26
- global opening.....4, 6
- keyless entry.....6
- luggage compartment.....7
- mode.....4
- multi point entry.....4
- opening the tailgate.....9
- single point entry.....4
- USB devices
  - connecting multiple devices.....117
- Used engine oil.....155
- Using adaptive cruise control.....96
- Using cruise control.....95
- Using the parking aids.....92
- Using the spare tyre
  - important information.....201
- Using wheel chocks.....201
- V**
- Valet mode.....65
  - deselecting.....66
- Vehicle alarm.....153
- Vehicle battery
  - connecting jump leads.....172
  - replacing.....174
  - warning symbols.....171
- Vehicle battery care.....171
- Vehicle build date.....207
- Vehicle cleaning
  - airbag covers.....161
  - alloy wheels.....159
  - automatic car wash.....159
  - carpets and mats.....161
  - engine compartment.....159
  - interior.....160–161
  - rear screen.....160
  - sunroof.....160
  - washer jets.....156
- Vehicle data recording.....205
- Vehicle identification
  - transmission number.....207
- Vehicle loading tyre pressures.....193
- Vehicle recovery
  - attaching the front tow eye.....202
  - steering column lock.....7
  - towing eyes.....202
  - transmission park release.....203
  - transporting the vehicle.....203
- Vehicle settings.....65
  - trip computer.....65
- Video media player
  - controls.....121
  - full screen view.....122
  - inhibited display.....122
- VIN number.....207
- Voice control.....123
  - navigation POI categories.....124
  - recognising your voice.....124
  - settings
    - command list.....64
    - operating guide.....64
    - preferences.....64
    - voicetags.....64
    - voice training.....64
  - training the system.....124
  - tutorial.....124
  - voicetags.....124
- Voice guidance.....138
- Volume
  - telephone.....129
- W**
- Warning lamps.....43
  - ABS.....44
  - ACC.....45
  - adaptive cruise control.....45
  - adaptive front lighting system (AFS).....45
  - airbags.....39, 45
  - automatic speed limiter.....45
  - brake.....43
  - critical warning message.....43
  - DSC active.....44
  - engine/transmission.....44
  - forward alert.....45
  - headlamp high beam.....45
  - high beam assist.....45

indicators.....	46	Wheels and tyres	
intelligent stop/start (green).....	45	age degradation.....	189
lamp test.....	43	changing a tyre.....	193
rear fog lamps.....	45	checking the pressures after a repair.....	196
seat belt.....	44	flat spots.....	189
side lights.....	46	Indian regulations.....	191
tyre pressure monitoring system		pressures.....	183
(TPMS).....	45	puncture repair.....	194
Warning triangle.....	158	puncture repair safety.....	194
Washer jets.....	156	repair kit.....	194
Washer reservoir		repair kit use.....	194
capacity.....	213	repair procedure.....	195
Washers.....	51	replacements.....	188
fluid specification.....	170	snow chains.....	190
fluid top up.....	170	temporary use spare.....	193
headlamps.....	52	TPMS.....	192
Washing		TPMS warning lamp.....	45
automatic car wash.....	159	tyre care.....	183
exterior paintwork.....	159	tyre speed ratings.....	183
removing grease.....	160	tyre wall markings.....	182
removing stains.....	161	valves.....	188
removing tar.....	160	wheel alignment.....	214
soft top.....	160	winter tyres.....	189
Water in fuel.....	148	Wheel spin.....	87
Weights		Windows	
gross vehicle weights.....	210	anti-trap protection.....	62
roof load.....	210	driver controls.....	
roof rack weight.....	210	one-touch operation.....	62
saloon.....	210	operation.....	61
sportbrake.....	210	reset.....	157
tow ball/hitch.....	77	sunroof blind.....	61
towing.....	77	sunroof operation.....	61
vehicle weights.....	210	sunroof reset.....	157
Wheel changing		Winter mode.....	87
important information.....	201	Winter park position.....	157
locking wheel nuts.....	201	Winter tyres.....	189
recommended process.....	199	Wipers and washers.....	51
safety warnings.....	198	driver controls.....	
spare wheel.....	200	fluid level.....	170
temporary spare wheel.....	201	rain sensor.....	52
tilt sensor.....	199	speed-dependent mode.....	52
use of spare tyre.....	201		
Wheel chocks use.....	201		