





While the Luggage compartment or tailgate is open, the locking platform and latch are exposed. Do not manually close the latch as it may also automatically 'soft-close' and trap items or body parts.



Care should be taken when manually closing the Luggage compartment or tailgate to engage the latch, as the soft-close feature will automatically close the latch. Possible injury may occur.

To activate the soft-close feature, lower the Luggage compartment lid or tailgate onto the latch. It will then automatically move to the fully closed and latched position.

OPENING AND CLOSING THE POWERED TAILGATE



E152085



Make sure there is a minimum space of 1.0 m (39 in) above the rear of the vehicle before operating the tailgate. Insufficient space may result in damage to the vehicle.