

- Automatic recirculation.....68
- Automatic speed limiter
  - warning lamp.....41
- Automatic switch off of ACC.....98
- Automatic transmission.....83
  - gear selector.....84
  - gear shift warning lamp.....41
  - shift paddles.....84
  - temporary manual selection.....84
- Auto zoom (navigation).....139
- Auxiliary device connection.....115
- Auxiliary power sockets.....74
- B**
- Battery
  - boost starting.....178
  - care.....176
  - charging.....179
  - connecting jump leads.....177
  - disconnecting jump leads.....178
  - luggage compartment access with a discharged battery.....77
  - maintenance.....176
  - replacing.....179
  - using a starting aid.....178
  - warning symbols.....176
- Battery backed sounder.....11
- Blinds.....61
  - rear window.....60
- Blind spot monitor
  - closing vehicle sensing.....55
  - displayed messages.....56
  - sensor blockage.....56
- Bluetooth
  - compatibility.....131
  - pairing
    - via the phone.....131
  - portable media
    - pairing.....115–116
    - playing.....115
  - telephone.....130
    - icons.....132
    - overview.....130
    - phonebook.....134
    - safety.....131
- Bonnet
  - closing.....161
  - opening.....161
- Booster seats for larger children.....32
- Boost starting.....178
- Brakes
  - ABS warning lamp.....40
  - electronic brake force distribution.....89
  - emergency assist.....100
  - emergency brake assist.....89
  - fluid check.....173
  - fluid specification.....174
  - fluid top up.....174
  - handbrake.....89
  - high level brake lamp.....162
  - important information.....89
  - parking brake warning lamp.....39
  - warning lamp (amber).....40
  - warning lamp (red).....39
- Bulbs
  - changing a bulb.....162
  - license plate.....162
  - number plate.....162
  - rear lamps.....162
  - specification.....217
- C**
- Call volume.....134
- Cameras
  - rear camera.....92
- Capacities.....217
  - engine oil.....217
  - fuel tank.....217
  - washer reservoir.....217
- Car-wash.....165
- CD player
  - CD loading.....102
  - portable media pairing.....115–116
  - portable media playing.....115
- Change a connected phone.....132
- Changing a bulb.....162
- Changing a fuse.....180