

FUEL CONSUMPTION

The fuel consumption figures shown in the following table, have been calculated using a standard testing procedure (the new EC test procedure from Directive 99/100/EC), and produced in accordance with The Passenger Car Fuel Consumption (Amendment) Order 1996.

Under normal use, a vehicle's actual fuel consumption figures may differ from those achieved through the test procedure, depending on driving technique, road and traffic conditions, environmental factors, vehicle load and condition.

Variant	Urban l/100 km (mpg)	Extra-urban l/100 km (mpg)	Combined l/100 km (mpg)	CO ² emissions g/km
3.0L Diesel				
Standard wheelbase	7.9 l/100 km (35.8 mpg)	5.7 l/100 km (49.6 mpg)	6.5 l/100 km (43.5 mpg)	171
Long wheelbase	7.9 l/100 km (35.8 mpg)	5.7 l/100 km (49.6 mpg)	6.5 l/100 km (43.5 mpg)	171
3.0L Diesel with Stop/Start				
Standard wheelbase	7.1 l/100 km (39.8 mpg)	5.5 l/100 km (51.4 mpg)	6.1 l/100 km (46.3 mpg)	159
Long wheelbase	7.7 l/100 km (36.7 mpg)	5.6 l/100 km (50.4 mpg)	6.3 l/100 km (44.8 mpg)	167
2.0L Petrol				
Standard wheelbase	13.6 l/100 km (20.8 mpg)	6.8 l/100 km (41.5 mpg)	9.3 l/100 km (30.4 mpg)	216
Long wheelbase	13.6 l/100 km (20.8 mpg)	6.8 l/100 km (41.5 mpg)	9.3 l/100 km (30.4 mpg)	216
2.0L Petrol with Stop/Start				
Standard wheelbase	11.7 l/100 km (24.1 mpg)	6.7 l/100 km (42.2 mpg)	8.5 l/100 km (33.2 mpg)	199
Long wheelbase	11.7 l/100 km (24.1 mpg)	6.7 l/100 km (42.2 mpg)	8.5 l/100 km (33.2 mpg)	199
3.0L Petrol - Supercharged				
Standard wheelbase	14.6 l/100 km (19.3 mpg)	7.4 l/100 km (38.2 mpg)	10.0 l/100 km (28.2 mpg)	234
Long wheelbase	14.6 l/100 km (19.3 mpg)	7.4 l/100 km (38.2 mpg)	10.0 l/100 km (28.2 mpg)	234

Fuel and refuelling

Variant	Urban l/100 km (mpg)	Extra-urban l/100 km (mpg)	Combined l/100 km (mpg)	CO ² emissions g/km
3.0L Petrol - Supercharged with Stop/Start				
Standard wheelbase	13.5 l/100 km (20.9 mpg)	7.4 l/100 km (38.2 mpg)	9.6 l/100 km (29.4 mpg)	244
Long wheelbase	13.5 l/100 km (20.9 mpg)	7.4 l/100 km (38.2 mpg)	9.6 l/100 km (29.4 mpg)	244
3.0L Petrol - Supercharged - All wheel drive				
Standard wheelbase	15.2 l/100 km (18.6 mpg)	7.8 l/100 km (36.2 mpg)	10.5 l/100 km (26.9 mpg)	224
Long wheelbase	15.2 l/100 km (18.6 mpg)	7.8 l/100 km (36.2 mpg)	10.5 l/100 km (26.9 mpg)	224
3.0L Petrol - Supercharged - with All wheel drive and Stop/Start				
Standard wheelbase	14.4 l/100 km (19.6 mpg)	7.8 l/100 km (36.2 mpg)	9.9 l/100 km (28.5 mpg)	234
Long wheelbase	14.4 l/100 km (19.6 mpg)	7.8 l/100 km (36.2 mpg)	9.9 l/100 km (28.5 mpg)	234
5.0L Petrol - Normally aspirated				
Standard wheelbase	16.7 l/100 km (16.9 mpg)	8.0 l/100 km (35.3 mpg)	11.2 l/100 km (25.2 mpg)	260
Long wheelbase	16.7 l/100 km (16.9 mpg)	8.0 l/100 km (35.3 mpg)	11.2 l/100 km (25.2 mpg)	260
5.0L Petrol - Normally aspirated with Stop/Start				
Standard wheelbase	15.7 l/100 km (18.0 mpg)	8.2 l/100 km (34.4 mpg)	10.9 l/100 km (25.9 mpg)	254
Long wheelbase	15.7 l/100 km (18.0 mpg)	8.2 l/100 km (34.4 mpg)	10.9 l/100 km (25.9 mpg)	254
5.0L Petrol - Supercharged with Stop/Start				
Standard wheelbase	16.9 l/100 km (16.7 mpg)	8.6 l/100 km (32.8 mpg)	24.4 l/100 km (11.6 mpg)	270
Long wheelbase	16.9 l/100 km (16.7 mpg)	8.6 l/100 km (32.8 mpg)	24.4 l/100 km (11.6 mpg)	270
5.0L Petrol - Supercharged Super Sport / XJ-R				