


# Fluid level checks

## FLUID FILLER LOCATIONS

2.0 litre petrol engine




E144236

1. Washer fluid.
2. Brake fluid (right-hand drive vehicles).
3. Engine oil.
4. Brake fluid (left-hand drive vehicles).
5. Coolant.
6. Power steering.
7. Engine oil dipstick.



**Do not drive the vehicle if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.**

## 3.0 and 5.0 litre petrol engines



E155509

1. Washer fluid.
2. Brake fluid (right-hand drive vehicles).
3. Engine oil (3.0L engine).
4. Engine oil (5.0L engine).
5. Brake fluid (left-hand drive vehicles).
6. Coolant (3.0L engine).
7. Power steering (5.0L engine).
8. Power steering (3.0L engine).
9. Coolant (5.0L engine).



**Do not drive the vehicle if there is a possibility that leaked fluid will come into contact with a hot surface, such as the exhaust.**