

Dynamic stability control (DSC).....	86
DSC active warning lamp.....	40
DSC off warning lamp.....	40
switching between DSC and tracDSC.....	87
switching off.....	87
switching on.....	87
E	
Easy route.....	141
Electric parking brake.....	89
Electric seats.....	13
head restraints.....	19
position memory.....	14
recalling a memory position.....	15
restricted seat travel.....	15
Electric windows	
operation.....	60
Electronic brake force distribution.....	89
Electronic data.....	209
Emergency (navigation).....	143
Emergency brake assist.....	89, 100
Emergency key locking.....	12
Emergency release	
luggage compartment.....	76
Engine	
antifreeze level.....	172
compartment opening.....	161
coolant level.....	172
diesel.....	152
diesel fuel.....	151
diesel particulate filter (DPF).....	159
oil level.....	170
petrol fuels.....	150
running-in.....	158
specifications.....	212
starting	
keyless start backup.....	80
switching off.....	79
Engine/transmission warning lamp.....	40
Engine compartment	
fluid filler locations.....	168
Engine compartment cleaning.....	165
Engine covers	
refitting.....	161
removal.....	161
Engine oil	
capacity.....	217
Engine starting.....	79
failure to start.....	80
Engine temperature warning lamp.....	39
Ensembles for DAB radio stations.....	110
Entering a destination.....	140
Entering the vehicle	
entry and exit mode.....	22
global opening.....	6
keyless entry.....	6
passive entry.....	6
Ethanol.....	150
EU conformity (navigation system).....	149
Event data recording.....	209
Executive class rear seats.....	16
massage.....	18
passenger seat away.....	14
remote seats.....	17
Exiting the vehicle	
arming the alarm.....	12
closing mislock.....	10
door locks and release levers.....	9
double locking.....	9
emergency locking.....	12
full alarm.....	10
global closing.....	10
interior locks.....	9
keyless locking.....	10
lock confirmation.....	9
passive arming.....	11
perimeter alarm.....	11
single locking.....	9
Exterior cleaning.....	165
Exterior lamps	
bulb changing.....	162
bulb specification.....	217
Exterior mirrors	
electric.....	51
manual.....	51
mirror dip when reversing.....	52
External temperature	
warning lamp.....	41