

# Audio/video overview

- Long press to scroll through the audio/video source selections, e.g. in My music: iPod, Bluetooth, stored CD etc.
9. Press to increase the volume for any source.
10. Press to decrease the volume for any source.
11. Seek up:  
Short press:
- To select the next radio preset.
  - To select the next track on the chosen audio source - CD, MP3 etc.
  - When telephone is in use, press to scroll up lists of calls or phonebook entries.
  - To select the next TV channel on the channel list or the next DVD chapter.
- Long press:
- To auto seek up the frequency to the next radio station.
12. Seek down:  
Short press:
- To select the previous radio preset.
  - To select the previous track or start of current track on the chosen audio source - CD, MP3 etc.
  - When telephone is in use, press to scroll down lists of calls or phonebook entries.
  - To select the previous TV channel on the channel list or the previous DVD chapter.
- Long press:
- To auto seek down the frequency to the next radio station.

## AUDIO SETTINGS


To view the **Audio settings** menu, touch the **Setup** soft key on the **Home menu** screen. Then on the **Setup** menu, touch the **Audio** soft key.

To adjust the sound settings:

- Touch the **Tone** soft key. Touch the + or - soft keys to adjust Bass, Treble or Subwoofer levels.

To adjust balance and fade:

- Touch the **Balance/Fade** soft key.



E132537

Touch the arrow soft keys to move the sound focal point to the desired area of the vehicle. Alternatively, touch the sound focal point and 'drag' it to the required position.

To adjust surround sound settings:

- If **Meridian Reference** is available, touch the **Meridian**, **DPLIIx** or **DTS Neo:6** soft keys to select **2D surround**. Select **Stereo** to switch **2D surround** off.

**Note:** Surround sound options are not available for certain sources where the surround sound mode is set automatically.

## LOADING DISCS



Do not force the disc into the slot.