

locking wheel nuts.....	203
recommended process.....	202
safety warnings.....	201
tilt sensor.....	202
use of spare tyre.....	203

Wheels and tyres

age degradation.....	194
changing a tyre.....	196
checking the pressures after a repair.....	199
flat spots.....	193
Indian regulations.....	195
pressures.....	191
puncture repair.....	197
puncture repair safety.....	197
repair kit.....	197
repair kit use.....	197
repair procedure.....	198
replacements.....	193
snow chains.....	194
temporary use spare.....	196
TPMS.....	196
TPMS warning lamp.....	41
tyre care.....	191
tyre speed ratings.....	191
tyre wall markings.....	190
valves.....	193
wheel alignment.....	218
winter tyres.....	194

Wheel spin.....86

Windows

anti-trap protection.....	62
one-touch operation.....	61
operation.....	60
reset.....	163
side window blinds.....	61
sunroof reset.....	163

Winter mode

stability control.....	86
------------------------	----

Winter park position.....	163
---------------------------	-----

Winter tyres.....	194
-------------------	-----

Wipers and washers.....	49
-------------------------	----

fluid level.....	175
------------------	-----

rain sensor.....	50
------------------	----

speed-dependent mode.....	50
---------------------------	----

X

Xenon headlamps.....	162
----------------------	-----

