


WIPER OPERATION



E153973

1. Automatic rain sensing mode (AUTO): The front wipers will respond and adapt automatically to the ambient rain conditions, selecting the appropriate wiper frequency for the prevailing conditions. The sensitivity of the system can be adjusted by rotating the collar (2).
2. Rotate the collar to adjust the sensitivity of the automatic rain sensing mode when position (1) is selected. The higher the sensitivity position the more responsive the system will become. When automatic rain sensing mode is selected, or when sensitivity is increased, the system will perform a single wipe.
3. Low speed continuous wipe.
4. High speed continuous wipe.



Make sure the wipers are switched off before entering a car wash. If the automatic rain sensing system operates during the car washing process, damage may occur to the wiper mechanism.



Do not operate the windscreen wipers on a dry screen.



In freezing or very hot conditions, make sure that the wipers have not stuck to the windscreen before operating.



Remove any snow, ice or frost from the windscreen, around the wiper arms and blades, and the screen scuttle, before operating the wipers.

5. Pull the stalk towards the driver for a single wipe, or hold for further continuous wipes.
6. Windscreen wash/wipe: Press and release to start a wash/wipe programme consisting of a number of low speed wipes. Washer fluid is sprayed during the up-stroke of the first 2 wipes. Continue to hold if additional washer fluid is required. A few seconds after the programme finishes a drip wipe will clear any residual fluid from the windscreen.

Note: Check and top-up the washer fluid level at least every week, **175, CHECKING THE WASHER FLUID LEVEL.**



Drip wipe on the windscreen can be enabled/disabled by a Dealer/Authorised Repairer.



Washer fluid dispensing during both the up and down strokes of the wipers can be enabled/disabled by a Dealer/Authorised Repairer.

Note: If the wipers leave smears on the glass after the car has been washed, this may be due to wax or other residue. Should this occur, clean the glass with washer fluid.

Note: The windscreen will no longer be wiped effectively and the automatic rain sensing function will degrade if the wipers become worn. Always replace worn or damaged wiper blades as soon as possible.