






-  Power steering fluid will damage painted surfaces. Soak up any spillage with an absorbent cloth immediately and wash the area with a mixture of car shampoo and water.
 - 1. Clean the filler cap before removing to prevent dirt from entering the reservoir.
 - 2. Remove the filler cap.
 - 3. Top-up the reservoir until the fluid level is between the **MIN** and **MAX** marks. For the power steering fluid specification, see **213, LUBRICANTS AND FLUIDS**.
 - 4. Replace the filler cap.
- 2. Open the filler cap.
 - 3. Top-up the reservoir with the specified washer fluid until the fluid is visible in the filler neck, see **213, LUBRICANTS AND FLUIDS**.
 - 4. Close the filler cap.

CHECKING THE WASHER FLUID LEVEL

 **Some screen washer products are flammable, do not allow screen washer fluid to come into contact with naked flames or sources of ignition.**

 **If the vehicle is operated in temperatures below 4°C (40°F), use a washer fluid with frost protection.**

 Only screen washer fluid products which are approved for automotive use should be used and then only in accordance with the manufacturer's instructions.

 Take care to avoid spillage, particularly if an undiluted or high concentration is being used. If spillage occurs, wash the affected area immediately with water.

The washer reservoir supplies the windscreen and headlamp washer jets.

Check and top-up the reservoir level at least every week, see **168, FLUID FILLER LOCATIONS**.

Operate the washers periodically to check that the nozzles are clear and properly directed.

TOPPING UP THE WASHER FLUID

1. Clean the filler cap before opening to prevent dirt from entering the reservoir.