

- Changing a wheel
 - locking wheel nuts.....203
 - recommended process.....202
 - safety warnings.....201
 - Charging the vehicle battery.....179
 - Chassis number.....211
 - Child safety
 - booster seats.....32
 - check list.....28
 - child seats.....27
 - ISOFIX anchor points.....29
 - larger children on booster seats.....32
 - lock and window inhibitor.....27
 - positioning.....29
 - tether straps.....31
 - Cleaning
 - airbag covers.....167
 - alloy wheels.....165
 - automatic car wash.....165
 - engine compartment.....165
 - exterior.....165
 - paintwork.....165
 - glass.....165
 - interior.....166–167
 - leather.....166
 - park assist sensors.....165
 - parking aids sensors.....165
 - polishing.....166
 - rear screen.....166
 - removing grease.....166
 - removing stains.....167
 - removing tar.....166
 - seat belts.....167
 - sensors and cameras.....165
 - sunroof.....166
 - using a car-wash.....165
 - Climate control
 - automatic recirculation.....68
 - front.....66
 - heated and cooled seats.....68
 - heated seats.....68
 - rear.....71
 - Climate seats.....68
 - Closing
 - luggage compartment.....75
 - Closing the bonnet.....161
 - Closing vehicle sensing.....55
 - Cold weather driving
 - diesel particulate filter (DPF).....160
 - Compact disc.....102
 - Condensation (headlamps).....46
 - Conformity declarations.....149, 221
 - Connecting jump leads.....177
 - Convenience mode.....7
 - Coolant
 - checking the level.....172
 - specification.....173
 - top up.....173
 - Covers
 - refitting.....161
 - removal.....161
 - Critical warning messages.....39
 - Cruise control.....95
 - ACC driving hints.....98
 - ACC follow mode.....96
 - ACC gap change.....97
 - ACC radar detection beam issues.....99
 - ACC set speed and follow mode
 - override.....97
 - adaptive cruise control.....96
 - adaptive cruise control malfunction.....99
 - follow mode.....96
 - forward alert in ACC.....99
 - low speed switch-off of ACC.....98
 - resume ACC follow mode.....98
 - resume ACC set speed.....98
 - using ACC.....96
 - warning lamp.....42
- ## D
- DAB radio
 - ensembles.....110
 - settings.....109
 - DAB radio controls.....108
 - Data recording.....209
 - Daytime running lamps.....44
 - Dealer locations.....144

Declarations of conformity.....	221	ACC gap change.....	97
navigation system.....	149	ACC low speed switch-off.....	98
Deselecting valet mode.....	65	ACC malfunction.....	99
Destination entry.....	140	ACC radar detection beam issues.....	99
postcode.....	142	ACC set speed and follow mode	
search area.....	140	override.....	97
Detection beam issues.....	99	activating intelligent stop/start.....	81
Diesel		active differential.....	87
filler flap.....	153	adaptive cruise control.....	96
fuel.....	151	after a collision.....	209
misfuel device.....	153	after deployment of the pedestrian protection	
sulphur content.....	151	system.....	209
water in fuel.....	152	arduous conditions.....	160
Diesel engines.....	152	automatic speed limiter.....	94
Diesel particulate filter (DPF).....	159	before starting.....	209
cold weather driving.....	160	blind spot monitor	
driving short distances.....	160	closing vehicle sensing.....	55
sulphur content.....	151	blind spot monitor messages.....	56
Differential control.....	87	brakes important information.....	89
Dimensions.....	215	daily checks.....	159
Direction indicators.....	44	deactivating intelligent stop/start.....	81
warning lamp.....	42	DSC active warning lamp.....	40
Disability modifications		electronic brake force distribution.....	89
airbags.....	35	emergency brake assist.....	89
Door mirrors.....	51	forward alert.....	99
blind spot monitor		forward alert warning lamp.....	42
closing vehicle sensing.....	55	gear shift warning lamp.....	41
sensors.....	56	rain sensor.....	50
Door transceiver		resume ACC follow mode.....	98
assistance.....	59	resume ACC set speed.....	98
erase all programming.....	58	running-in.....	158
garage door opener.....	57	sitting correctly.....	15
programming.....	57	using ACC.....	96
programming a single button.....	58	using cruise control.....	95
programming the garage door opener.....	57	weekly checks.....	159
rolling code device programming.....	58	Driving abroad	
Double locking.....	9	beam pattern.....	46
full alarm.....	10	headlamps.....	46
Drive away locking.....	6	Driving position memory.....	14
Driving		recalling a position.....	15
ACC automatic switch-off.....	98	Driving short distances	
ACC driving hints.....	98	diesel particulate filter (DPF).....	160
ACC follow mode.....	96	Dual view.....	121
ACC forward alert.....	99	controls.....	121