

Mass group		Size classes	Fixtures	Rear outboard seats
I =	9 to 18 kg (20 to 40 lb.) 9 months to 4 years	C/D A/B1/B	ISO R2/R3 ISO F2/F2X/F3	<b>X</b> <b>IUF</b>
II =	15 to 25 kg (33 to 55 lb.) 4 to 9 years	-	N/A	N/A
III =	22 to 36 kg (49 to 80 lb.) 8 to 12 years	-	N/A	N/A

**IUF** = Suitable for ISOFIX forward child restraint systems of universal category approved for use in the mass group.

**IL** = These ISOFIX child restraint systems are of the specific vehicle, restricted or semi-universal categories.

**X** = Not suitable for child restraint fitment in this mass group.

\* = Child seat suitable for use in these locations is the Britax/Römer Baby Safe Plus.

N/A = Not available.

**Note:** Ages given are approximate. In case of doubt, the child's weight, not age, should be used when considering an appropriate child seat.

## INSTALLING TETHER ANCHORAGE CHILD RESTRAINTS

**WARNING:** child restraint anchorages are designed to withstand only those loads imposed by correctly fitted child restraints. Under no circumstances are they to be used for adult seat belts, harnesses or for attaching other items or equipment to the vehicle.


**Always follow the child seat or restraint system manufacturer's instructions when fitting tether straps.**



**When fitting a child seat or restraint system, always pass the tether strap over the top of the seatback and beneath the head restraint.**



**If a child seat or restraint system is to be fitted to the centre seating position, the centre armrest must be in the stowed position (folded into the seat).**



1. Install the child restraint securely in one of the rear seating positions.
2. Pass the tether strap over the seatback and beneath the head restraint\*.