


## REAR CLIMATE CONTROL



E153559

To access the Rear climate menu, select **Rear climate** from the Front climate menu.

1. Temperature control: Rotate to adjust temperature (16°C - 28°C [59°F - 83°F]). The temperature is displayed on the touch screen (rear climate menu).
2. AUTO control: Press to switch automatic operation on.
3. Blower speed: Rotate to adjust blower speed.

With blower speed at minimum, rotate the control counter-clockwise to switch the climate system off. Press AUTO to turn on again.

4. Air distribution to face: Press to switch on/off. The switch indicator illuminates when on.
5. Air distribution to feet: Press to switch on/off. The switch indicator illuminates when on.
6. Seat temperature control: Press the red arrow to increase and the blue arrow to decrease the temperature. The LEDs illuminate to indicate the current setting.

# Heating and ventilation

7. Climatic seat zone control: Press to select full seat or seatback only ventilation. The switch indicators illuminate accordingly.
8. Air distribution to the feet: Touch to turn on/off.
9. Air distribution to the face: Touch to turn on/off.
10. Temperature adjustment: Select the red arrow to increase and the blue arrow to decrease the temperature. The temperature setting is displayed above the arrows.
11. **Auto**: Select to switch automatic operation on/off.
12. **Rear seats**: Select to adjust the rear seat temperature and ventilation settings.
13. **Rear panel lock**: Select to disable the rear climate control switches, to prevent the rear passengers from adjusting the rear climate settings. Select again to re-enable the controls.

In addition to the selectable controls, the rear climate menu displays symbols that indicate the status of heating and ventilation functions.

**Note:** *If the climate control system is switched off, pressing a rear AUTO button will switch the climate control system on.*

**Note:** *If the system is in Defrost mode, all rear controls are disabled and no airflow is available to the rear occupants.*