

LUGGAGE COMPARTMENT FUSE BOX

Fuse No	Rating (amps)	Fuse Colour	Circuit
F1	30A	Green	Right side Electronic Parking Brake (EPB)
F2	-	-	-
F3	-	-	-
F4	5A	Tan	Singapore road pricing
F5	-	-	-
F6	30A	Green	Power boot lid
F7	-	-	-
F8	5A	Tan	Telematics
F9	-	-	-
F10	-	-	-
F11	20A	Yellow	Front heated seat
F12	10A	Red	Seat movement logic and switch power
F13	10A	Red	Rear seat logic
F14	25A	Clear	Rear heated seat
F15	-	-	-
F16	10A	Red	Chassis control module
F17	10A	Red	Chassis control module (air suspension)
F18	10A	Red	Infotainment Master Controller (IMC) fan
F19	30A	Green	Fuel pump, Body control module, LSD
F20	20A	Yellow	Left side rear climate seat
F21	10A	Red	Headlamp control module, Camera, Auto high beam disable, Lane change merge assist, Park aid module, Interior mirror
F22	10A	Red	Adaptive cruise control, Continuously variable dampers
F23	-	-	-
F24	2A	Grey	Vehicle Information and Communication System (VICS)
F25	5A	Tan	Air suspension module
F26	-	-	-
F27	-	-	-

Fuses

Fuse No	Rating (amps)	Fuse Colour	Circuit
F28	-	-	-
F29	20A	Yellow	Right side rear climate seat
F30	-	-	-
F31	-	-	-
F32	30A	Green	Left side Electronic Parking Brake (EPB)
F33*	40A	Green	E-diff module
F34*	40A	Green	Front blower motor
F35*	60A	Yellow	Quiescent relay box
F36*	30A	Pink	Sunroof module
F37*	40A	Green	Air suspension
F38*	60A	Yellow	Air suspension control relay
F39	-	-	-

*Jaguar recommends that these fuses should only be serviced by a Dealer/Authorised Repairer.

Secondary luggage compartment fuse box

Fuse No	Rating (amps)	Fuse Colour	Circuit
F1	15A	Blue	Touch screen display
F2	10A	Red	Amplifier, Clock
F3	-	-	-
F4	10A	Red	Phone connect view, DAB radio, Navigation, TV
F5	15A	Blue	Integrated audio module
F6	15A	Blue	Rear seat entertainment
F7	-	-	-
F8	-	-	-
F9	-	-	-
F10	-	-	-
F11	-	-	-

Fuse No	Rating (amps)	Fuse Colour	Circuit
F12	-	-	-
F13	-	-	-
F14	-	-	-
F15	15A	Blue	Heating and ventilation module
F16	-	-	-