



Rear media

When Limousine mode is turned on, the rear passengers will have control of the total cabin Audio system, and any shared sources via the remote control.

- 6. **Lock:** Touch to lock or unlock the Rear media remote control.
- 7. **System:** Touch to switch the selected Rear media system on or off.
- 8. Forward/Skip for the selected screen.
- 9. Touch to play the right rear screen's audio through the vehicle's speaker system.
- Note: Only available when the Rear media system is in **Limo mode**.*
- 10. **Source:** Touch to select the Rear media source selection menu.
- 11. Play/Pause for the selected screen.
- 12. Touch to play the left rear screen's audio through the vehicle's speaker system.
- Note: Only available when the Rear media system is in **Limo mode**.*
- 13. Rewind/Skip for the selected screen.
- 14. Rear media source selection menu: Touch the required media button.
- 15. **Source:** Touch to return to the **Rear media** control screen.

REAR MEDIA REMOTE CONTROL



E151273

- 1. Press and release to turn off the screen. Press and hold to turn off the rear media system.
- 2. Left screen select/turn on.