

ENGINE COMPARTMENT FUSE BOX

Fuse No	Rating (amps)	Fuse Colour	Circuit
F1	-	-	-
F2	10A	Red	Engine management sensors (petrol & GTDI)
	5A	Tan	Engine and E-box cooling fans
F3	25A	Clear	Ignition coils (petrol & GTDI)
F4	30A	Green	Power wash pump
F5	40A	Orange	Main electrical power to module (petrol & GTDI)
F6	40A	Orange	Right side front screen heater and heated wiper
F7	30A	Green	Traction control module (AWD)
F8	10A	Red	Oxygen sensor (petrol & GTDI)
	5A	Tan	Active engine mount
F9	10A	Red	Engine cooling fan, Engine management (petrol & GTDI)
F10	-	-	-
F11	5A	Tan	S/C Intercooler water pump coil (petrol)
	-	-	Spare (GTDI)
F12	20A	Yellow	Oxygen sensors Bank A (petrol & GTDI)
	10A	Red	Engine management sensors
F13	20A	Yellow	Oxygen sensors Bank B (petrol) Spare (GTDI)
F14	5A	Tan	Adaptive cruise control
F15	20A	Yellow	Oxygen sensors (petrol)
	-	-	Spare (GTDI)
F16	5A	Tan	S/C Intercooler water pump coil feed (petrol)
	-	-	Spare (GTDI)
F17	5A	Tan	Pinion motor monitor
F18	15A	Blue	Horn
F19	30A	Green	Starter
F20	40A	Orange	Anti-lock brake system pumps
F21	25A	Clear	Anti-lock brake system valve
F22	15A	Blue	Right side LED headlamps

Fuse No	Rating (amps)	Fuse Colour	Circuit
F23	15A	Blue	Left side LED headlamps
F24	-	-	-
F25	-	-	-
F26	40A	Orange	Wiper motor
F27	5A	Tan	Monitor
F28	15A	Blue	Transmission control module
F29	5A	Tan	Dynamic stability control
F30	-	-	-
F31	-	-	-
F32	40A	Orange	Left side heated screen
F33	15A	Blue	S/C Intercooler water pump (petrol)
	-	-	Spare (GTDI)
F34	-	-	-
F35	80A	Black	Cooling fan