


SURROUND CAMERA SYSTEM

⚠ It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them when manoeuvring the vehicle.



E158504

The camera home page is accessed by using the Touch screen **Home menu**. Select **Extra features**, then select **Cameras** and then select the camera icon.

To adjust the camera settings, select **Settings**. See **105, REAR CAMERA**.

1. **Enlarge**: To enlarge a camera view, touch the image, then touch the **Enlarge** icon. Any 2 images can be selected and enlarged to view side-by-side on the screen. When viewing the 2 images, one of them can be selected to view as a full screen image. It can then be zoomed into and panned around using the magnifier and arrow icons.
2. **Proximity View**: Touch to select a combination of 3 images from the front and passenger side cameras.

Automatic Proximity View: When a forward or a reverse gear is selected, the forward or rear view will be displayed. Once the vehicle's speed exceeds 18 km/h (11 mph) or the return icon is pressed, the camera screen will disappear.

Note: Proximity view can be accessed at any time by touching Proximity View on the camera home page.

3. **Special Views**: Touch to display a selection of preset views. They are provided to assist with difficult manoeuvres and are:
 - **Kerb view**: Shows views from the 2 side cameras.
 - **Junction view**: Shows views from the 2 front cameras.
4. **Tow Assist**: Touch to display the trailer guidance set-up screen. See **86, TOW ASSIST**.

Note: The quality of the camera views may vary in different lighting conditions.

Note: To maintain optimum performance, the cameras should be kept free from ice, frost and dirt. See **217, SENSORS AND CAMERAS**.