Vehicle cleaning

Make sure the vehicle underside is cleaned as soon as possible after driving off-road.

ALLOY WHEELS

①

Only use approved wheel cleaning products.

GLASS SURFACES

Clean the rear window with a soft cloth to avoid damaging the heating element. Do not scrape the glass or use any abrasive cleaning fluid.

Mirror glass is particularly susceptible to damage. Wash with soapy water. Do not use abrasive cleaning compounds or metal scrapers to remove ice.

To avoid damaging the protective coating, only clean the interior side of the sunroof glass with a soft cloth. Do not scrape the glass or use abrasive cleaning fluids.

REAR SCREEN

To avoid damaging the heating elements when cleaning the inside of the rear screen, use only a soft damp cloth or chamois leather. Do not use solvents or sharp objects to clean the glass.

THE INTERIOR



Some cleaning products contain substances that are harmful and can cause health problems if used incorrectly and may cause damage to the vehicle interior. Make sure you read the manufacturer's instructions carefully.

FABRIC UPHOLSTERY



Never use soap, ammonia, bleach or other cleaners intended for use on hard surfaces.

Dinamica suede fabric should be cleaned regularly. Do not rub vigorously and do not use a steam machine. Dusting with a soft brush, a dry cloth or vacuum cleaner will be sufficient.

Do not use printed absorbent cloths or paper as they may transfer colour to the fabric.

LEATHER UPHOLSTERY



Use only cleaning products specifically designed for use on leather. Do not use solvents. Do not use chemical, alcohol, or abrasive materials, as they will cause rapid deterioration of the leather. The use of products which are not approved will invalidate your warranty.



If you are in any doubt as to which products to use, consult a Dealer/Authorised Repairer.

Leather should be cleaned and protected using Land Rover approved leather cleaner.

To prevent ingrained dirt and staining, inspect the seat upholstery regularly and clean every 1 to 2 months as follows:

- Wipe off fine dust from the seat surfaces using a clean, damp, non-coloured cloth. Change frequently to a clean area of cloth to avoid abrasive action on the leather surface. Avoid over wetting the leather.
- If this is not sufficient, use a cloth which has been dampened with warm soapy water and then wrung out. Use only mild non-caustic soap.
- Use Land Rover approved leather cleaner for heavily soiled areas. Dry off and rub with a clean soft cloth, changing surfaces regularly.