

ENGINE COMPARTMENT FUSE BOX

Fuse number	Rating (Amps)	Fuse colour	Circuits protected
1	5	Tan	Starter motor sensor
2	5	Tan	Voltage quality module
3*	80	-	Cooling fans
4*	60	-	Diesel - Glow plugs
5*	80	-	Electric power assisted steering (EPAS)
6	15	Blue	Oxygen sensors
7	5	Tan	Engine management, Air conditioning (A/C) compressor clutch, Intelligent stop/start motor
8	20	Yellow	Diesel and Petrol - Engine management control unit
9	10	Red	Diesel - Engine sensors
10	-	-	-
11	10	Red	Diesel and Petrol - Engine sensors
12	15	Blue	Diesel - Exhaust Gas Recirculation (EGR) bypass, water in fuel sensor
			Petrol - Ignition coils
13	10	Red	A/C compressor clutch
14	15	Blue	Diesel - Engine sensors
15*	40	Green	Starter motor
16*	100	-	PTC heater
17*	60	-	Passenger compartment fuse box
18*	60	-	Passenger compartment fuse box
19*	60	-	Luggage compartment fuse box
20*	60	-	Luggage compartment fuse box
21*	60	-	Voltage quality module, Luggage compartment fuse box
22*	30	Pink	Front wipers
23*	40	Green	Passenger compartment fuse box
24	-	-	-
25	-	-	-

Fuse number	Rating (Amps)	Fuse colour	Circuits protected
26*	40	Green	Anti-lock Braking System (ABS)
27*	40	Green	Passenger compartment fuse box
28*	40	Green	Heater blower
29*	30	Pink	Electric trailer brake (Australia)
30	15	Blue	Headlamp washer
31	15	Blue	Horns
32	20	Yellow	Anti-lock braking system (ABS)
33	5	Tan	Relay coils - Horn, Heated front screen, Fuel pump, Extended ignition
34*	40	Green	Heated front screen - left side
35*	40	Green	Heated front screen - right side
36	-	-	-
37	20	Yellow	Fuel pump
38	5	Tan	Steering wheel module
39	5	Tan	Adaptive cruise control (ACC)
40	5	Tan	Adaptive Front Lighting System (AFS) - Right headlamp
41	5	Tan	Adaptive Front Lighting System (AFS)- Left headlamp
42	5	Tan	Headlamp control, Dynamic headlamp levelling control unit
43	5	Tan	Rear view camera, Climate/Heated seat relay coils
44	10	Red	Heated steering wheel
45	-	-	-

*Land Rover recommends that these fuses should only be serviced by a Dealer/Authorised Repairer.