

- Make sure that a suitable breakaway cable or secondary coupling is used. Refer to the trailer manufacturer's instructions for guidance.
- Make sure that the tow ball is secure.
- Check the operation of all trailer lights.

## Australia only:

**Nose weight** must be a minimum of 7% of gross caravan/trailer weight, up to a maximum of 150 kg (330 lb).

## TRAILER ELECTRICAL CONNECTION



Attach only approved electrical connectors, which are in good condition, to the trailer socket.

The vehicle connector provides a 5 amp output which must not be exceeded. An accessory harness kit increasing output to 15 amp is available from a Dealer/Authorised Repairer.

When a trailer's electrical connection is made and the vehicle's direction indicators are used, the trailer warning indicator will flash in time with the direction indicators. See **49, TRAILER DIRECTION INDICATORS (GREEN)**.

## TRAILER STABILITY ASSIST (TSA)

When a trailer is attached, TSA will automatically detect when a trailer sway is developing. It will then gradually reduce vehicle speed by cutting engine power and applying the brakes to help regain control.

## HITCH GUIDANCE

Hitch guidance is a user selectable Touch screen feature that can aid the process of guiding the vehicle to a trailer tow hitch. Use Hitch guidance while reversing the vehicle to a trailer hitch.

Proceed as follows:

1. Select reverse gear. Dependent on the vehicle's specification, the Touch screen will automatically display selectable icons or a menu list. See **114, SURROUND CAMERA SYSTEM** or see **105, REAR CAMERA**.
2. Touch the Rear camera system's **Hitch guidance** icon or the Surround camera system's **Hitch guidance** tick, on the Touch screen to enable the Hitch guidance lines to be displayed.
3. Reverse the vehicle towards the trailer.
4. As the vehicle closes to within 600 mm (2 ft) of the trailer tow hitch, an automated zoom feature is operated to enlarge the view.
5. Continue the manoeuvre carefully until the vehicle and trailer are as close as required.

## TOW ASSIST

**Note:** Tow assist requires a connected trailer to be fitted with a tracking target sticker, which **must** be attached according to specific instructions. Ask your Dealer/Authorised Repairer for details.



E134952

**Note:** This feature may not operate with all trailer designs.

Tow assist aids trailer reversing, by displaying guidelines on the Touch screen.

Tow assist becomes active when a trailer/caravan is attached to the vehicle and the trailer's electrical plug is attached to the vehicle's socket.