

PASSENGER COMPARTMENT FUSE BOX

Left side A pillar fuse box




E159451

| Fuse No | Rating (amps) | Fuse Color | Circuit |
|---------|---------------|------------|--|
| F1 | 30A | Green | Electric Parking Brake (EPB) (left side) |
| F2 | - | - | - |
| F3 | - | - | - |
| F4 | - | - | - |
| F5 | 10A | Red | Instrument panel control, Instrument panel fan |

Fuses

| Fuse No | Rating (amps) | Fuse Color | Circuit |
|---------|---------------|------------|---|
| F6 | 15A | Blue | Convertible roof (front latch) |
| F7 | - | - | - |
| F8 | 5A | Tan | Keyless vehicle module (logic) |
| F9 | 15A | Blue | Convertible roof (down lock) |
| F10 | 10A | Red | Air conditioning clutch |
| F11 | 25A | Clear | Heated front seat |
| F12 | 5A | Tan | Seat switch power |
| F13 | 10A | Red | Chassis control module (spoiler), JaguarDrive control switch |
| F14 | - | - | - |
| F15 | 25A | Clear | Tailgate |
| F16 | 30A | Green | Electric Parking Brake (EPB) (right side) |
| F17 | 10A | Red | Adaptive damping control, Chassis control module |
| F18 | - | - | - |
| F19 | 30A | Green | Fuel pump |
| F20 | - | - | - |
| F21 | 10A | Red | Rear camera, Headlamps, Blind Spot Monitoring (BSM), Park Distance Control, Interior mirror |
| F22 | 5A | Tan | Right side headlamp motor |
| F23 | 5A | Tan | Left side headlamp motor |
| F24 | 5A | Tan | Headlamp leveling |
| F25 | 10A | Red | Instrument panel control, Instrument panel fan |
| F26 | 5A | Tan | Gateway module |
| F27 | - | - | - |
| F28 | - | - | - |
| F29 | 10A | Red | Rear camera, Headlamps, Blind Spot Monitoring (BSM), Park Distance Control, Interior mirror |
| F30 | 5A | Tan | Normal mode (or Transport mode) |

Passenger side foot-well fuse box



E159424

| Fuse No | Rating (amps) | Fuse Color | Circuit |
|---------|---------------|------------|--|
| F1 | 5A | Tan | Radio Frequency (RF) receiver, Interior motion sensor, Tire pressure monitoring sensor |
| F2 | - | - | - |
| F3 | - | - | - |
| F4 | 5A | Tan | CAN gateway module |
| F5 | 5A | Tan | Anti-lock Braking System (ABS), Steering angle sensor |
| F6 | - | - | - |
| F7 | - | - | - |
| F8 | 30A | Green | Right side seat (power 2) |
| F9 | 5A | Tan | Electric Parking Brake (EPB) |
| F10 | 5A | Tan | Adaptive damping control |
| F11 | - | - | - |

Fuses

| Fuse No | Rating (amps) | Fuse Color | Circuit |
|---------|---------------|------------|--|
| F12 | 5A | Tan | Reverse lamps and Mirror dimming inhibit |
| F13 | - | - | - |
| F14 | 5A | Tan | Brake pedal switch |
| F15 | 30A | Green | Heated rear screen |
| F16 | - | - | - |
| F17 | - | - | - |
| F18 | - | - | - |
| F19 | 5A | Tan | Powertrain control module, Electronic control module |
| F20 | 10A | Red | Heated steering wheel |
| F21 | 10A | Red | Passenger air bag disable lamp (overhead console) |
| F22 | 5A | Tan | Transmission control module, Rear differential, Electronic transmission switch (ignition signal) |
| F23 | 5A | Tan | Fuse box suppression |
| F24 | 5A | Tan | Right side rear fog lamp |
| F25 | 5A | Tan | Left side rear fog lamp |
| F26 | - | - | - |
| F27 | - | - | - |
| F28 | 25A | Clear | Door module (right side) |
| F29 | - | - | - |
| F30 | - | - | - |
| F31 | 5A | Tan | Rain sensor, Climate control sensors |
| F32 | 25A | Clear | Door module (left side) |
| F33 | - | - | - |
| F34 | 10A | Red | Cubby box lock, Stowage box lock |
| F35 | - | - | - |
| F36 | - | - | - |
| F37 | - | - | - |
| F38 | 15A | Blue | Front screen washer |
| F39 | - | - | - |

| Fuse No | Rating (amps) | Fuse Color | Circuit |
|---------|---------------|------------|--|
| F40 | - | - | - |
| F41 | - | - | - |
| F42 | 30A | Green | Left side seat (power 1) |
| F43 | 10A | Red | Active exhaust |
| F44 | - | - | - |
| F45 | 30A | Green | Right side seat (power 1) |
| F46 | 30A | Green | Left side seat (power 2) |
| F47 | - | - | - |
| F48 | - | - | - |
| F49 | - | - | - |
| F50 | - | - | - |
| F51 | 5A | Tan | Steering wheel switches |
| F52 | 20A | Yellow | Accessory socket (center) |
| F53 | 20A | Yellow | Accessory socket/cigar lighter (cubby box) |
| F54 | - | - | - |
| F55 | - | - | - |
| F56 | 10A | Red | Restraint control module |
| F57 | 10A | Red | Glove box lamp, Reading lamps |
| F58 | - | - | - |
| F59 | 10A | Red | Door soft close (close and reverse) |
| F60 | 5A | Tan | Occupant control sensor |
| F61 | 5A | Tan | Immobiliser antenna unit |
| F62 | - | - | - |
| F63 | - | - | - |
| F64 | - | - | - |
| F65 | - | - | - |
| F66 | - | - | - |
| F67 | - | - | - |

Fuses

| Fuse No | Rating (amps) | Fuse Color | Circuit |
|---------|------------------|------------|---------|
| F68 | - | - | - |
| F69 | - | - | - |