SETTING A DESTINATION

- From the Navigation menu, touch Destination entry.
- 2. Touch **Address** from the **Destination** screen and input the town name or zipcode.
- Once sufficient letters have been entered, touch **Ok** or **List** to display all the possible towns.
- **4.** If necessary, use the scroll arrows to the left of the list to search up or down. Select the town you require.
- Now enter the road name. Once sufficient letters have been entered, touch **0k** or **List** to display all the possible roads.
- Select the road you require. Enter the house number of the address (if known) and then touch **0k** to confirm.
- If the house number is not known, select Ok; the mid-point of the road is then used as the destination.
- The map screen showing the selected destination details is displayed. Touch GO to calculate the default quick route, or Review route for alternative routes.
- **9.** Touch **GO** to start the trip.

START GUIDANCE

After selecting a **Destination**, the system will calculate the route:

- There is now a choice to select 3 Routes, Change route, or select GO, to start navigation guidance.
- Touch 3 Routes to display a choice of 3 different route options on the map. The roads on the map are drawn in 3 different colors to highlight each route.
- 3. Select route **Quick**, **Short**, or **Alt**. by touching the respective box displayed on the right side of the map.

- 4. Touch Change Route followed by Route preferences to change the route settings. Press Ok for changes to take effect. if a destination is already set, touch Waypoint to add a waypoint in the trip, if required.
- **5.** When you have made your selection, if any, touch **GO**.

Note: As you approach an intersection, in addition to the voice guidance, an inset on the map will display an enlarged view of the intersection.

AVOID POINTS

When calculating a route, an area to avoid can be set and stored:

- 1. From the Nav menu, touch More....
- 2. Select Stored locations.
- 3. Select Avoid points.
- 4. Select Add.
- Select the location of the area to avoid from the **Destination entry** menu. Touch **Ok** to activate the view, where the size of the area to avoid can be set
- Touch **0k** to activate the area to avoid. The size of the area can be adjusted by using the '+' or '-' symbols.
- Touch **0k**; the area to avoid is now set and stored.

To edit or delete an area to avoid from the stored list:

- From the Nav menu, touch More... and select Stored locations.
- 2. Select Avoid points.
- 3. From the sub-menu, select Edit or Delete.

EASY ROUTE

In Route options, Easy Route can be turned On or Off