

WEEKLY CHECKS

- Engine oil level.
- Engine coolant check.
- Brake fluid level.
- Windshield washer fluid level.
- Tire pressures and condition.
- Operate air conditioning.

Note: *The engine oil level should be checked more frequently if the vehicle is driven for prolonged periods at high speeds.*

SAFETY IN THE GARAGE

WARNING

If the vehicle has been driven recently, do not touch the engine, exhaust and cooling system components, until the engine has cooled.

WARNING

Never leave the engine running when the vehicle is in a garage. Exhaust gases are poisonous and can cause unconsciousness and death if inhaled.

WARNING

Do not work beneath the vehicle with a jack as the only means of support.

WARNING

Keep your hands and clothing away from drive belts, pulleys and fans. Some fans may continue to operate after the engine has stopped.

WARNING

Remove metal wristbands and jewelry, before working in the engine compartment.

WARNING

Do not touch electrical leads or components while the engine is running, or with the ignition switched on.

WARNING

Do not allow tools or metal parts of the vehicle to make contact with the battery leads or terminals.

FUEL SYSTEM

WARNING

Under no circumstances should any part of the fuel system be dismantled or replaced by anyone other than a suitably qualified vehicle technician.

WARNING

Make sure that sparks and open flames are kept away from the engine compartment.

WARNING

Wear protective clothing, including, where practicable, gloves made from an impervious material.

USED ENGINE OIL

NOTICE

Prolonged contact with engine oil may cause serious skin disorders, including dermatitis and cancer of the skin. Always wash thoroughly after contact.