#### WEEKLY CHECKS

- Engine oil level.
- Engine coolant check.
- Brake fluid level.
- Windshield washer fluid level.
- Tire pressures and condition.
- Operate air conditioning.

**Note:** The engine oil level should be checked more frequently if the vehicle is driven for prolonged periods at high speeds.

#### SAFETY IN THE GARAGE

### AWARNING

If the vehicle has been driven recently, do not touch the engine, exhaust and cooling system components, until the engine has cooled.

# **A**WARNING

Never leave the engine running when the vehicle is in a garage. Exhaust gases are poisonous and can cause unconsciousness and death if inhaled.

## **A**WARNING

Do not work beneath the vehicle with a jack as the only means of support.

## AWARNING

Keep your hands and clothing away from drive belts, pulleys and fans. Some fans may continue to operate after the engine has stopped.

## **A**WARNING

Remove metal wristbands and jewelry, before working in the engine compartment.

# **A**WARNING

Do not touch electrical leads or components while the engine is running, or with the ignition switched on.

### AWARNING

Do not allow tools or metal parts of the vehicle to make contact with the battery leads or terminals.

#### **FUEL SYSTEM**

#### **A**WARNING

Under no circumstances should any part of the fuel system be dismantled or replaced by anyone other than a suitably qualified vehicle technician.

### AWARNING

Make sure that sparks and open flames are kept away from the engine compartment.

### AWARNING

Wear protective clothing, including, where practicable, gloves made from an impervious material.

#### **USED ENGINE OIL**

#### NOTICE

Prolonged contact with engine oil may cause serious skin disorders, including dermatitis and cancer of the skin. Always wash thoroughly after contact.