

7. **Station list** (FM only): Select to view a list of available stations on the waveband. The list can be sorted by **Frequency**, **Name**, or **Category** (pop, news, sport, etc.) by selecting the appropriate soft key. Touch to select the chosen station.  
If the stations are sorted by category, touch the chosen category to view and select a corresponding station.
8. **Frequency input**: Select to enter a known frequency of a station on the current waveband, using the numeric keypad that appears. Select **OK**, or wait for 2 seconds to tune to the entered frequency.
9. **Station presets**: Each waveband has 6 preset positions.
  - Touch and release to tune to the station stored on that preset.
  - Touch and hold to store the current station on that preset (the radio will mute while the station is stored and then beep).
  - Use the seek buttons on the steering wheel to change to the next or previous preset station.

## RADIO BROADCAST DATA SYSTEM (RBDS)

Your radio is equipped with RBDS, which enables the audio unit to receive additional information with normal FM radio signals.

**Note:** *Not all FM radio stations broadcast RBDS information.*

Select **Settings**, then select **RBDS On** to view or alter the RBDS settings:

- The RBDS enables stations to be categorized by program type, e.g., rock music, current affairs, news, etc. The list is then available to view via the **Station list** soft key.
- Note:** *If the selected station is equipped with HD Radio™ technology and HD Radio is switched on (see **114, HD Radio TECHNOLOGY**), the HD Radio service name and program information will be displayed.*

## ALERTS

The **ALERT!** option in the **Category** section of the **Station list** will alert you to a crisis of national or international importance. Any radio broadcast, or other audio playback, will be interrupted. When such a broadcast is made, an ALERT pop-up will be displayed on the Touch screen. The pop-up can be canceled, but the audio alert will continue to broadcast until finished, or until the radio station or audio source is changed.