

**A**

- About this handbook.....2
- Accessories.....155
- Active differential control.....92
- Active exhaust.....83
- Adaptive dynamics.....93
- Adaptive front lighting system.....51
  - warning lamp.....47
- Adaptive headlamps.....51
- Adjusting button illumination.....53
- Adjusting switch illumination.....53
- Age degradation (tires).....196
- Air bags
  - curtain.....35
  - deployment.....35, 37
  - disability modifications.....40
  - front.....35
  - locations.....34
  - maintenance.....155
  - obstructions.....36
  - occupant sensing.....38
  - service information.....39
  - side.....35
  - warning lamp.....37, 47
- Air conditioning
  - automatic recirculation.....71
  - fluid top up.....155
  - front.....70
- Air quality sensor.....71
- Alarm
  - automatic relocking and arming.....16
  - deactivating.....16
  - perimeter.....16
  - security sensor fault.....16
- Alarm arming.....15
- Ambient temperature changes
  - tire pressure compensation.....195
- Anchor points (luggage).....76
- Anti-lock braking system (ABS) warning lamp.....46
- Anti-trap protection
  - windows.....65
- Approach lamps.....51
- Arming the alarm.....15
- Assistance
  - InControl link.....133
- Audible warnings.....49
- Audio
  - automatic station retune.....113
  - CD loading.....108
  - changing portable media device.....123
  - connecting portable media devices.....120
  - DVD player controls.....124
  - full screen view.....125
  - HD digital channels.....114
  - HD radio reception.....114
  - licensing.....109-110
  - portable media connections.....120
  - portable media controls.....118
  - portable media pairing.....122
  - portable media playing.....121
  - radio controls.....112
  - radio national alert.....113
  - satellite radio controls.....115
  - satellite radio reception.....117
  - satellite subscription.....116
  - touch screen controls.....107
  - video player controls.....124
- Auto lamps
  - wiper detection.....51
- Automatic locking.....10, 16
- Automatic recirculation.....71
- Automatic speed limiter
  - warning lamp.....47
- Automatic transmission.....86
  - shift paddles.....88
  - temporary manual selection.....88
- Auto zoom (navigation).....141
- Auxiliary device connection.....121
- Avoiding tire flat spots.....196

**B**

- Battery
  - boost starting.....174
  - care.....171
  - charging.....174
  - connecting jump leads.....173