
### **USING THE PARKING AID**



# **A**WARNING

The Parking aid system is not a substitute for driving safely with due care and attention. Drivers should not assume that this feature will correct errors of judgement while driving.

# **A**WARNING

Parking aids may not detect moving objects, such as children and animals, until they are dangerously close. Always exercise extreme caution when maneuvering and always use the mirrors.

# AWARNING

It remains the driver's responsibility to detect obstacles and estimate the vehicle's distance from them. Some overhanging objects, barriers, small children, animals, thin obstructions, or painted surfaces may not be detected by the system.

### AWARNING

The Parking aid system may not function under all speeds, weather, and road conditions.

### NOTICE

If accessories are fitted to the rear of the vehicle, particular care must be taken when reversing. The rear sensors will only indicate the distance from the bumper to the obstacle.

- 1. Parking aid switch: Press to switch the system on and off.
- 2. Parking aid detection range.

When Reverse  $(\mathbf{R})$  is selected, the front and rear parking sensors are activated automatically and the switch indicator will illuminate.

When Drive (**D**) is selected, the front sensors must be activated by pressing the Parking aid switch; the switch indicator will illuminate.

To switch off the system when active, press the switch; the switch indicator will extinguish.