


## CONFIGURABLE DYNAMIC MODE



E149073

Vehicles with configurable dynamics, allow the Dynamic mode settings to be configured via the Touch screen for selected characteristics, with a choice between Normal and Dynamic settings. See **69, EXTRA FEATURES**.

1. Touch to display and adjust configurable settings, when in Dynamic mode.
2. **Stopwatch:** Touch to display live timings and split timings.  
*Note: Up to 99 split times can be saved and reviewed.*  
*Note: When the **Press to split** soft key has been selected, it is disabled for 3 seconds while the split time is displayed.*
3. **G Meter:** Touch to display the current amount and direction of G Force.
4. **Pedal Graph:** Touch to display a brake and accelerator graph, or a live display.

5. Indicates status: Dynamic or Normal.
6. Touch to display a description of the function.
7. **Engine:** Touch to select the **Dynamic** or **Normal** setting.
8. **Steering:** Touch to select the **Dynamic** or **Normal** setting.
9. **Suspension:** Touch to select the **Dynamic** or **Normal** setting.
10. Displays which dynamic functions are selected.
11. **Gear Shift:** Touch to select the **Dynamic** or **Normal** setting.
12. **Factory Setup:** Touch to switch **on/off**.
13. **My Setup:** Touch to switch the user settings **on/off**.
14. Indicates status, **on/off**.