


MAIN MENU



E151123

⚠ WARNING

Do not adjust the Touch screen controls, or allow the system to distract the driver, while the vehicle is moving. Driver distraction can lead to accidents, causing serious injury or death.

1. **More...**: Displays the other Nav menu screen.
2. **Cancel guidance**: Cancels current route guidance.
3. **Destination entry**: Provides a choice of options for entering a destination.

4. **Previous destination**: Displays previous destinations entered.
5. **Display/Hide POI**: Turns the POI (Point Of Interest) icons on the map on/off.
6. When a destination is set, the Jaguar logo is replaced by a soft key which enables the last voice instruction to be repeated.
7. **Route voice guidance**: Allows the voice guidance messages to be turned off for the current trip. The soft key is highlighted while voice guidance is enabled.

Navigation system

8. **POI shortcuts:** Touch an icon to list available POIs close to the vehicle's position.
9. **Return to map:** Advances to the main map screen.
10. **Detour:** Allows a detour from the current route.
11. **Nav setup:** Settings for the Navigation system.
12. **Route options:** Allows a selection of various options for the route.
13. **TMC (Traffic Message Channel):** Not used for entering a destination but, when enabled, will provide data about road conditions and any events that may affect the trip.
14. **Stored locations:** Manages the stored locations.