




## CHARGING THE VEHICLE BATTERY

-  The battery must be disconnected and removed from the vehicle before charging. Failure to do so could result in damage to the vehicle's electrical system.
-  Battery disconnection, removal, and replacement, should only be carried out by qualified personnel. Consult a Dealer/Authorised Repairer.

## REPLACING THE VEHICLE BATTERY

-  Battery disconnection, removal, and replacement, should only be carried out by qualified personnel. Consult a Dealer/Authorised Repairer.



Used batteries must be disposed of correctly, as they contain a number of harmful substances. Seek advice on disposal from a Dealer/Authorised Repairer and/or the local authority.