CHARGING THE VEHICLE BATTERY

- The battery must be disconnected and removed from the vehicle before charging. Failure to do so could result in damage to the vehicle's electrical system.
- Battery disconnection, removal, and replacement, should only be carried out by qualified personnel. Consult a Dealer/Authorised Repairer.

REPLACING THE VEHICLE BATTERY

Battery disconnection, removal, and replacement, should only be carried out by qualified personnel. Consult a Dealer/Authorised Repairer.



Used batteries must be disposed of correctly, as they contain a number of harmful substances. Seek advice on disposal from a Dealer/Authorised Repairer and/or the local authority.