

Pairing using the Touch screen

1. Switch on your phone or device's **Bluetooth** wireless technology device connection. Make sure that your phone or device is in **Bluetooth** wireless technology device discoverable mode, sometimes referred to as find me mode (see your phone or device's operating instructions for more information).
2. Switch the ignition on and make sure the Touch screen is active.
3. Select **General settings**.
4. From the displayed list, select **Bluetooth**.
5. The system searches for a phone or device and, if found, the phone or device displays on the screen.
If the phone or device is not found, **NO DEVICES FOUND** displays.
***Note:** The phone/device list can store up to 4 entries.*
6. A Passkey number appears on the phone or device. If this number matches the number on the Touch screen, touch **Yes**.
7. Once a phone or device is paired, it appears on the connected device's list and on the **PHONE** screen and it appears in the **Bluetooth, List of paired devices** section.

INSTRUCTIONAL VIDEO



E173293

CHANGING THE CONNECTED PHONE OR DEVICE

Up to 4 mobile phones or devices can be paired with the vehicle in the same way. However, only 2 can be connected and ready for use as a phone or device at any one time (one for phone and one for media).

To connect a different paired phone to the vehicle:

1. Switch the ignition on and make sure the Touch screen is active.
2. Touch the **Phone** soft key or the phone hard key.
3. From the **PHONE** menu screen, select **Change device**. See **157, TELEPHONE SYSTEM OVERVIEW**.
4. A menu will appear. Select a paired device from the list.

DELETING A PAIRED PHONE OR DEVICE

To delete a phone or device from the system:

1. In **General settings**, select **Bluetooth**.
2. From the list, select **List of paired devices**.
3. Select the phone or device to be deleted.
4. From the list, select **Delete pairing** to delete the phone or device from the system.