

Engine compartment	
fluid filler locations.....	203
Engine compartment cleaning.....	200
Engine covers	
refitting.....	187
removal.....	187
Engine oil	
capacity.....	253
Engine starting.....	100
Engine temperature warning lamp.....	51
Entering the vehicle	
entry and exit mode.....	28
global opening.....	9
keyless entry.....	8
luggage compartment.....	10
passive entry.....	8
tailgate operation.....	10
unlocking mode.....	8
Ethanol.....	174
Event data recording.....	244
Exhaust fluid	
diesel.....	176
Exiting the vehicle	
arming the alarm.....	17
closing mislock.....	14
door locks and release levers.....	13
double locking.....	13
emergency locking.....	17
full alarm.....	15
global closing.....	14
interior locks.....	13
keyless locking.....	14
lock confirmation.....	14
passive arming.....	16
perimeter alarm.....	15
single locking.....	13
Exterior cleaning.....	200
Exterior lamps	
bulb changing.....	187
bulb specification.....	254
Exterior mirrors	
electric.....	65
manual.....	65
mirror dip when reversing.....	66
External temperature	
warning lamp.....	53
Extra features.....	78
F	
Flat spots.....	226
Fluids	
brake	
check.....	207
specification.....	208
top up.....	208
capacities.....	253
clutch check.....	207
coolant	
specification.....	207
top up.....	207
engine oil	
check.....	204
filler locations.....	203
oil	
top up.....	205
specifications.....	248
washer fluid.....	209
check.....	209
specification.....	209
Fog lamps	
warning lamps	
rear.....	53
Follow	
override.....	130
Follow mode	
entering.....	129
gap change.....	130
gap changing.....	130
override.....	131
resume.....	131
Forward alert.....	133
Forward alert in ACC	
object detection.....	133
Forward alert warning lamp.....	55
Front airbags.....	43
Front climate control.....	79
automatic recirculation.....	80
Front parking aids.....	115