

Engine compartment		
fluid filler locations.....	203	
Engine compartment cleaning.....	200	
Engine covers		
refitting.....	187	
removal.....	187	
Engine oil		
capacity.....	253	
Engine starting.....	100	
Engine temperature warning lamp.....	51	
Entering the vehicle		
entry and exit mode.....	28	
global opening.....	9	
keyless entry.....	8	
luggage compartment.....	10	
passive entry.....	8	
tailgate operation.....	10	
unlocking mode.....	8	
Ethanol.....	174	
Event data recording.....	244	
Exhaust fluid		
diesel.....	176	
Exiting the vehicle		
arming the alarm.....	17	
closing mislock.....	14	
door locks and release levers.....	13	
double locking.....	13	
emergency locking.....	17	
full alarm.....	15	
global closing.....	14	
interior locks.....	13	
keyless locking.....	14	
lock confirmation.....	14	
passive arming.....	16	
perimeter alarm.....	15	
single locking.....	13	
Exterior cleaning.....	200	
Exterior lamps		
bulb changing.....	187	
bulb specification.....	254	
Exterior mirrors		
electric.....	65	
manual.....	65	
mirror dip when reversing.....	66	
External temperature		
warning lamp.....	53	
Extra features.....	78	
F		
Flat spots.....	226	
Fluids		
brake		
check.....	207	
specification.....	208	
top up.....	208	
capacities.....	253	
clutch check.....	207	
coolant		
specification.....	207	
top up.....	207	
engine oil		
check.....	204	
filler locations.....	203	
oil		
top up.....	205	
specifications.....	248	
washer fluid.....	209	
check.....	209	
specification.....	209	
Fog lamps		
warning lamps		
rear.....	53	
Follow		
override.....	130	
Follow mode		
entering.....	129	
gap change.....	130	
gap changing.....	130	
override.....	131	
resume.....	131	
Forward alert.....	133	
Forward alert in ACC		
object detection.....	133	
Forward alert warning lamp.....	55	
Front airbags.....	43	
Front climate control.....	79	
automatic recirculation.....	80	
Front parking aids.....	115	