
STORAGE COMPARTMENTS



E165456

 Glovebox: Pull the release handle to open. The glovebox can be locked/unlocked using the emergency key blade, mounted in the vehicle's Smart key. See 6, UNLOCKING THE VEHICLE.

Note: When Valet mode is selected, the glove box will not open.

2. Front Cup holders.

Do not drink, or use the cup holders when driving.

- Cubby box: Push and hold the release button and then lift to open the cubby box lid. To close, lower the lid and then lightly press to engage the catch.
- 4. Rear cup holders: Pull the tag at the top of the stowed rear seat's armrest and lower.