

UNBLOCKING WASHER JETS



Do not operate the washer jets during adjustment. Windscreen washer fluid may cause irritation to the eyes and skin. Always read and observe the washer fluid manufacturer's instructions.

If a washer jet becomes blocked, use a thin strand of wire to unblock the jet by inserting the wire into the jet. Make sure that the wire is completely removed after unblocking.

WIPERS SERVICE POSITION



To avoid damage to the bonnet, do not lift the wiper blades when they are in the normal parked position.

Note: *The Smart key must remain in the vehicle while the wiper blades are replaced.*

Before changing a wiper blade, the wiper arms must be set in the 'service' position as follows:

1. Make sure the ignition is turned OFF.
2. Turn the ignition ON and then OFF again.
3. Immediately press the wiper stalk to its lowest position (as if to command a single wipe, see **62, WIPER OPERATION**), hold this position while turning ON the ignition again.
The wipers will move to their service position.
4. When the new parts have been fitted, turn the ignition OFF. This will return the wipers to the park position.

Note: *Fit only replacement wiper blades that are identical to the original specification.*

SUNROOF RESET

Make sure that the conditions, listed below, are met before carrying out the sunroof reset procedure:

- The ambient air temperature needs to be within the range of 5°C to 65°C.
- The vehicle has to be stationary.
- The vehicle's battery is sufficiently charged and the electrical connections are good.

Reset the sunroof as follows:

1. Switch the ignition on.
2. Manually fully close the sunroof and the sunblind. Release the switches. See **73, ELECTRIC WINDOWS**.



Before closing the sunroof, make sure that no occupants have any part of their body in a position where it could be trapped. Even with an Anti-trap system death or serious injury could occur. See 75, SUNROOF ANTI-TRAP MECHANISM.

3. Fully press and hold the front of the sunroof switch for 10 seconds, to start the reset cycle. Continue to hold the front of the sunroof switch.

Note: *If the switch is released, then the whole procedure will have to be repeated.*

4. . The reset cycle will:
 - Fully open the sunblind.
 - Fully open and then fully close the sunroof.
 - Fully close the sunblind.



The Anti-trap system is disabled during the reset cycle. Make sure that no occupants have any part of their body in a position where it could be trapped.

5. Once the reset cycle has completed and the sunblind has stopped moving, release the switch.

The sunroof and the sunblind can now be operated as normal.