

## CHECKING THE WASHER FLUID LEVEL



E106759



**Do not allow the screen washer fluid to come into contact with naked flames or sources of ignition.**



**If the vehicle is operated in temperatures below 4°C (40°F), use a washer fluid with frost protection.**



Only use approved washer fluid.



Take care to avoid spillage, particularly if an undiluted or high concentration is being used. If spillage occurs, wash the affected area immediately with water.

1. Clean the washer fluid reservoir filler cap before opening, to prevent dirt from entering the reservoir.
2. Open the reservoir filler cap by pulling up on the front lug.
3. Check that the fluid level is visible in the filler neck.

## TOPPING UP THE WASHER FLUID

The washer fluid reservoir supplies the front and rear screen washer jets and also the headlamp washer jets.

Check and top up the reservoir level at least every week. Always top up with screen washer fluid to prevent freezing.

Operate the washer switches periodically to check that the nozzles are clear and properly directed.

1. Top up the reservoir until the fluid level is visible in the filler neck.
2. Replace the filler cap by pressing down until an audible click is heard.