WEIGHTS

Variant	Vehicle weight from kg (lbs)	Gross Vehicle Weight (GVW)¹ kg (lbs)	Maximum front axle load² kg (lbs)	Maximum rear axle load² kg (lbs)
3.0L petrol	1 635 (3 605)	2 220 (4 894)	1 100 (2 425)	1 220 (2 690)
2.0L petrol (240 PS)	1 520 (3 351)	2 120 (4 674)	1 040 (2 293)	1 220 (2 690)
2.0L petrol (200 PS)	1 515 (3 340)	2 120 (4 674)	1 040 (2 293)	1 220 (2 690)
2.0L diesel (180 PS) (with manual transmission)	1 490 (3 285)	2 135 (4 707)	1 030 (2 271)	1 220 (2 690)
2.0L diesel (163 PS) (with manual transmission)	1 435 (3 164)	2 100 (4 630)	1 000 (2 205)	1 200 (2 646)
2.0L diesel (180 PS) (with automatic transmission)	1 505 (3 318)	2 135 (4 707)	1 030 (2 271)	1 220 (2 690)
2.0L diesel (163 PS) (with automatic transmission)	1 450 (3 197)	2 100 (4 630)	1 000 (2 205)	1 200 (2 646)

Max. luggage compartment load (all vehicles): 35 kg (77 lbs).

The maximum permitted luggage compartment load can be exceeded, provided the requirements regarding the maximum permissible axle weights and tyre pressures are followed.

¹The maximum permissible weight of the vehicle, including passengers and load.

For further information on the technical specifications, see the Jaguar website: www.jaguar.com.



The maximum permitted roof load, including the weight of the roof rack/roof bars, is 75 kg (165 lb). The roof load must be included when calculating the Gross Vehicle Weight (GVW).

² The front and rear axle maximum loads cannot be reached simultaneously, as this will exceed the GVW limit.

Technical specifications

Jaguar recommend that only approved accessories are used. If in any doubt, consult a Dealer/Authorised Repairer before fitting a roof rack/roof bars or carrying a roof load.

For towing weights, see **88, TOWING WEIGHTS**.