


## AM/FM RADIO CONTROLS

### FM Radio Presets screen



E171498

- Stations:** Touch to select the list of available stations for the chosen radio source.
  - Source:** Touch to select the media source list. See **143, MEDIA CONTROLS**.
  - Status icons:** Showing the connected phone's battery level and network signal strength. The Traffic Announcement (**TA**) icon will also be displayed, if TA is currently switched on. See **144, AUDIO SETTINGS**.
  - Seek down:** Touch to auto-seek down the frequency to the next radio station.  
*Note:* In some markets, additional buttons are available to enable manual tuning.
  - The selected frequency and station name.
  - Seek up:** Touch to auto-seek up the frequency to the next radio station. The seek buttons on the steering wheel can also be used to change to the next or the previous frequency.
- Note:* In some markets, additional buttons are available to enable manual tuning.
- Waveband image (if available).
  - Information from the selected station.
  - Station presets:**
    - Touch to tune to the station stored on that preset.
    - Touch and hold to store the current station on that preset.
  - Touch to scroll through the preset stations.
  - Touch to select the **General settings** menu. Select **Media** and then **Radio**, where the following features can be activated/deactivated:
    - Manual tune.**
    - Radiotext** (FM only).
    - Alternative Frequency (AF)** (FM only).
    - Regionalization** (FM only).

***Note:** Settings options may vary, depending on the market.*