
## AM/FM RADIO CONTROLS

## FM Radio Presets screen



- Stations: Touch to select the list of available stations for the chosen radio source.
- 2. **Source**: Touch to select the media source list. See **143**, **MEDIA CONTROLS**.
- Status icons: Showing the connected phone's battery level and network signal strength. The Traffic Announcement (TA) icon will also be displayed, if TA is currently switched on. See 144. AUDIO SETTINGS.
- **4.** Seek down: Touch to auto-seek down the frequency to the next radio station.

**Note:** In some markets, additional buttons are available to enable manual tuning.

- **5.** The selected frequency and station name.
- **6.** Seek up: Touch to auto-seek up the frequency to the next radio station.

  The seek buttons on the steering wheel can also be used to change to the next or the previous frequency.

**Note:** In some markets, additional buttons are available to enable manual tuning.

- 7. Waveband image (if available).
- **8.** Information from the selected station.
- **9.** Station presets:
  - Touch to tune to the station stored on that preset.
  - Touch and hold to store the current station on that preset.
- **10.** Touch to scroll through the preset stations.
- 11. Touch to select the General settings menu. Select Media and then Radio, where the following features can be activated/deactivated:
  - Manual tune.
  - Radiotext (FM only).
  - Alternative Frequency (AF) (FM only).
  - Regionalization (FM only).

## Media

**Note:** Settings options may vary, depending on the market.