


AM/FM RADIO CONTROLS

FM Radio Presets screen



E171498

1. **Stations:** Touch to select the list of available stations for the chosen radio source.
2. **Source:** Touch to select the media source list. See **143, MEDIA CONTROLS**.
3. **Status icons:** Showing the connected phone's battery level and network signal strength. The Traffic Announcement (**TA**) icon will also be displayed, if TA is currently switched on. See **144, AUDIO SETTINGS**.
4. **Seek down:** Touch to auto-seek down the frequency to the next radio station.
***Note:** In some markets, additional buttons are available to enable manual tuning.*
5. The selected frequency and station name.
6. **Seek up:** Touch to auto-seek up the frequency to the next radio station. The seek buttons on the steering wheel can also be used to change to the next or the previous frequency.
7. Waveband image (if available).
8. Information from the selected station.
9. Station presets:
 - Touch to tune to the station stored on that preset.
 - Touch and hold to store the current station on that preset.
10. Touch to scroll through the preset stations.
11. Touch to select the **General settings** menu. Select **Media** and then **Radio**, where the following features can be activated/deactivated:
 - **Manual tune.**
 - **Radiotext** (FM only).
 - **Alternative Frequency** (AF) (FM only).
 - **Regionalization** (FM only).

Note: *Settings options may vary, depending on the market.*