


AM/FM RADIO CONTROLS

FM Radio Presets screen



E171498

1. **Stations:** Touch to select the list of available stations for the chosen radio source.
2. **Source:** Touch to select the media source list. See **143, MEDIA CONTROLS**.
3. **Status icons:** Showing the connected phone's battery level and network signal strength. The Traffic Announcement (**TA**) icon will also be displayed, if TA is currently switched on. See **144, AUDIO SETTINGS**.
4. **Seek down:** Touch to auto-seek down the frequency to the next radio station.
***Note:** In some markets, additional buttons are available to enable manual tuning.*
5. The selected frequency and station name.
6. **Seek up:** Touch to auto-seek up the frequency to the next radio station. The seek buttons on the steering wheel can also be used to change to the next or the previous frequency.
- Note:** In some markets, additional buttons are available to enable manual tuning.*
7. Waveband image (if available).
8. Information from the selected station.
9. Station presets:
 - Touch to tune to the station stored on that preset.
 - Touch and hold to store the current station on that preset.
10. Touch to scroll through the preset stations.
11. Touch to select the **General settings** menu. Select **Media** and then **Radio**, where the following features can be activated/deactivated:
 - **Manual tune.**
 - **Radiotext** (FM only).
 - **Alternative Frequency** (AF) (FM only).
 - **Regionalization** (FM only).

Note: *Settings options may vary, depending on the market.*