

Navigation system

THE NAVIGATION SYSTEM

Navigation instruction is by map and turn information displayed on the Touch screen and can be complemented by voice guidance, if required. The system uses signals from Global Positioning System (GPS) satellites, combined with information from vehicle sensors and from data stored on the SD card, to establish the true position of the vehicle.

Using this combination of data sources, the vehicle's navigation computer enables you to plan and follow a route map to your desired destination.

The Touch screen is used to control navigation via menus, text screens, and map displays.

 **Operate the system only when it is safe to do so.**

Note: The Navigation system fitted to your vehicle does not support speed camera alerts.

The requirements of national Road Traffic Regulations always apply.

Observation of traffic signs and local traffic regulations always take priority.

The Navigation system serves solely as an aid to navigation. In particular, the Navigation system cannot be used as an aid to orientation when visibility is poor.

GPS signals may occasionally be interrupted due to physical barriers, such as tunnels and roads, under raised highways.

However, direction and speed sensors on the vehicle will minimise any adverse effect on the Navigation system. Normal operation will resume once the obstruction has been passed.

Under certain conditions, it is possible for the vehicle's position shown on the screen to be incorrect. This may happen when:

- Driving on a spiral ramp in a building.
- Driving on, or beneath, elevated roads.

- Two roads are close and parallel.
- The vehicle has been transported to another destination.
- The vehicle has been rotated on a turntable.
- The vehicle's battery has been disconnected.

NAVIGATION SD CARD




E171145

The Navigation SD card reader is located in the front centre cubby box. See **87, STORAGE COMPARTMENTS**. Make sure that the SD card is located correctly in the card reader before operating the Navigation system.

For updates to the Navigation system's maps, visit: www.jaguar.com/map-updates/incontrol-touch, or contact a Jaguar Retailer.

Note: If for any reason the SD card is ejected while the Navigation system is in operation, locate the SD card correctly in the card reader and touch **Retry** soft key on the Touch screen, when prompted.

USING THE NAVIGATION SYSTEM

 **In the interests of safety, only operate, adjust, or view the system when it is safe to do so.**



The Navigation system is not a substitute for driving safely, with due care and attention. Drivers should not assume that a feature will correct errors in judgement when driving. It is the driver's responsibility to stay alert, drive safely, and be in control of the vehicle at all times, relative to the prevailing conditions. It is also the driver's responsibility to determine the safety of the route suggested by the Navigation system. The Navigation system may not function properly in all circumstances.



Do not allow the system to distract the driver while the vehicle is moving. Driver distraction can lead to accidents, causing serious injury or death.

To access the Navigation system, press the Navigation button or touch the **NAVIGATION** area on the **HOME** screen.

Note: *The Navigation system will remain active until the ignition is switched off and the driver's door is opened.*

This will show the current vehicle position. Touch the **NAV MENU** soft key to display the **NAV MENU** screen.

At this point, the first time user should set up personal preferences in the **NAV SET-UP** area. These settings are applied, whenever the Navigation system is used.